



H5W H3W User Manual

Software Version: 2.4.2

Release Date: 2021/02/4

Directory

Directory.....	3
1 Picture.....	6
2 Table.....	8
3 Safety Instruction.....	9
4 Overview.....	11
4.1 Overview.....	11
4.2 Packing Contents.....	11
5 Desktop Installation.....	14
5.1 PoE and the use of external power adapters.....	14
5.2 Desktop and wall mounted method.....	15
6 Appendix Table.....	17
6.1 Appendix I - Icon.....	17
6.2 Appendix II - Keyboard character query table.....	17
7 Introduction to the User.....	20
7.1 Key description.....	20
7.2 Using Handset / Hands-free Speaker.....	23
7.3 Idle Screen.....	24
7.4 Phone Status.....	24
7.5 Making Phone Calls.....	26
7.6 Web Management.....	27
7.7 SIP Configurations.....	29
8 Basic Function.....	30
8.1 Answering Calls.....	30
8.1.1 Talking.....	30
8.1.2 Make / Receive Second Call.....	31
8.2 End of the Call.....	32
8.3 Redial.....	32
8.4 Auto-Answering.....	32
8.5 Mute.....	33
8.5.1 Mute the Call.....	33
8.5.2 Ringing Mute.....	33
8.6 Call Hold/Resume.....	34
8.7 Call Transfer.....	34
8.8 Call Waiting.....	35

8.9 Anonymous Call.....	36
8.9.1 Anonymous Call.....	36
8.9.2 Ban Anonymous Call.....	36
8.10 Hotline.....	37
9 Advance Function.....	38
9.1 MCAST.....	38
9.2 MWI (Message Waiting Indicator)	38
10 Web Configurations.....	39
10.1 Web Page Authentication.....	39
10.2 System >> Information.....	39
10.3 System >> Account.....	39
10.4 System >> Configurations.....	39
10.5 System >> Upgrade.....	40
10.6 System >> Auto Provision.....	43
10.7 System >> Tools.....	46
10.8 System >> Reboot Phone.....	46
11 Network.....	47
11.1 Network >> Wi-Fi Settings.....	47
11.2 Network >> Basic.....	48
11.3 Network >> Service Port.....	49
11.4 Network >> VPN.....	50
11.5 Network >> Advanced.....	50
11.6 Line >> SIP.....	51
11.7 Line >> SIP Hotspot.....	56
11.8 Line >> Dial Plan.....	59
11.9 Line >> Action Plan.....	62
11.10 Line >> Call Firewall.....	错误！未定义书签。

Firewall Settings

Number:

Line:

All

Type:

Restricted Incoming Calls

Allow Incoming Type:

All

Add

Firewall Options

Number:

Delete

Delete All

Modify

Firewall List

Number	Type	Line

.....错误！未定义书签。

11.11 Line >> Basic Settings.....	62
11.12 Line >> RTCP-XR.....	63
11.13 Phone settings >> Features.....	63
11.14 Phone settings >> Media Settings.....	66
11.15 Phone settings >> MCAST.....	67
11.16 Phone settings >> Action.....	68
11.17 Phone settings >> Time/Date.....	68
11.18 Phone Settings >> Time Plan.....	69
11.19 Phone settings >> Tone.....	69
11.20 Phone settings >> Advanced.....	70
11.21 Phonebook >> Advanced.....	71
11.22 Call Log.....	72
11.23 Function Key >> Softkey.....	72
11.24 Security >> Web Filter.....	73
11.25 Security >> Trust Certificates.....	74
11.26 Security >> Device Certificates.....	74
11.27 Security >> Firewall.....	75
11.28 Device Log >> Device Log.....	77
12 Trouble Shooting.....	78
12.1 Get Device System Information.....	78
12.2 Reboot Device.....	78
12.3 Reset Device to Factory Default.....	78
12.4 Screenshot.....	78
12.5 Network Packets Capture.....	79
12.6 Get Log Information.....	80
12.7 Common Trouble Cases.....	80

1 Picture

Picture 1	- Device installation.....	15
Picture 2	- Wall-mounted installation.....	16
Picture 3	- Connecting to the Device.....	16
Picture 4	- H5W Instruction of Keypad	20
Picture 5	- Screen layout/default home screen.....	24
Picture 6	- Scroll icon.....	24
Picture 7	- The Phone status.....	25
Picture 8	- WEB phone status.....	26
Picture 9	- Open the voice channel and dial the number.....	27
Picture 10	- Call number.....	27
Picture 11	- Landing page.....	28
Picture 12	- Web SIP registration.....	29
Picture 13	- Answering calls.....	30
Picture 14	- Talking interface.....	30
Picture 15	- The second call interface.....	31
Picture 16	- Two way calling.....	32
Picture 17	- Web page to start auto-answering.....	33
Picture 18	- Mute the call.....	33
Picture 19	- Ringing mute.....	34
Picture 20	- Call hold interface.....	34
Picture 21	- Transfer interface.....	35
Picture 22	- Web call waiting setting.....	35
Picture 23	- Web call waiting tone setting.....	36
Picture 24	- Enable Anonymous web page call.....	36
Picture 25	- Page Settings blocking anonymous call.....	36
Picture 26	- Hotline set up on webpage.....	37
Picture 27	- Web page firmware upgrade.....	41
Picture 28	- Page auto provision Settings.....	44
Picture 29	- Network Priority.....	47
Picture 30	- WiFi Settings.....	48
Picture 31	- Service Port Settings.....	49
Picture 32	-SIP hotspot.....	57
Picture 33	- SIP hotspot server configuration.....	58
Picture 34	- SIP hotspot client configuration.....	59
Picture 35	- Dial plan settings.....	60
Picture 36	- Custom setting of dial - up rules.....	60

Picture 37	- Dial rules table (1).....	61
Picture 38	- Dial rules table (2).....	62
Picture 39	- MCAST.....	67
Picture 40	- Tone settings on the web.....	70
Picture 41	- Page screen Settings.....	71
Picture 42	- Web Filter settings.....	73
Picture 43	- Web Filter Table.....	74
Picture 44	- Certificate of settings.....	74
Picture 45	- Device certificate setting.....	75
Picture 46	- Network firewall Settings.....	75
Picture 47	- Firewall Input rule table.....	76
Picture 48	- Delete firewall rules.....	77
Picture 49	- Screenshot.....	79
Picture 50	- Web capture.....	79

2 Table

Table 1	- Hardware Interface Description.....	16
Table 2	- Keypad Icons.....	17
Table 3	- Look-up Table of Characters.....	17
Table 4	- H5W Instruction of Keypad	20
Table 5	- Firmware upgrade.....	42
Table 6	- Auto Provision.....	44
Table 7	- Service port.....	49
Table 8	- QoS & VLAN.....	51
Table 9	- Line configuration on the web page.....	51
Table 10	- SIP hotspot Parameters.....	57
Table 11	- Phone dialing methods.....	60
Table 12	- Dial - up rule configuration table.....	60
Table 13	- IP camera.....	62
Table 14	- Set the line global configuration on the web page.....	62
Table 15	- VQ RTCP-XR Settings.....	63
Table 16	- General function Settings.....	63
Table 17	- Voice settings.....	66
Table 18	- Multicast parameters.....	67
Table 19	- Time&Date settings.....	68
Table 20	- Softkey configuration.....	72
Table 21	- Side Key configuration.....	73
Table 22	- Network Firewall.....	76
Table 23	- Trouble Cases.....	80

3 Safety Instruction

Please read the following safety notices before installing or using this unit. They are crucial for the safe and reliable operation of the device.

- Please use the external power supply that is included in the package. Other power supply may cause damage to the phone and affect the behavior or induce noise.
- Before using the external power supply in the package, please check the home power voltage. Inaccurate power voltage may cause fire and damage.
- Please do not damage the power cord. If power cord or plug is impaired, do not use it because it may cause fire or electric shock.
- Do not drop, knock or shake the phone. Rough handling can break internal circuit boards.
- This phone is designed for indoor use. Do not install the device in places where there is direct sunlight. Also do not put the device on carpets or cushions. It may cause fire or breakdown.
- Avoid exposure the phone to high temperature or below 0°C or high humidity.
- Avoid wetting the unit with any liquid.
- Do not attempt to open it. Non-expert handling of the device could damage it. Consult your authorized dealer for help, or else it may cause fire, electric shock and breakdown.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean it. Wipe it with a soft cloth that has been slightly dampened in a mild soap and water solution.
- When lightning, do not touch power plug, it may cause an electric shock.
- Do not install this phone in an ill-ventilated place. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement: The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

4 Overview

4.1 Overview


H5W is a low-end WIFI product phone, with advanced design, high cost performance, paperless office, which greatly improves the production efficiency of the enterprise; not only a desk phone, but also a boutique placed in the living room or office .

H5W, which are the latest generation of IP phone developed on the basis of the X series, inheriting many excellent features of the previous X series traditional phone, such as high-definition voice and high-performance echo cancellation full duplex speaker, fast / gigabit Ethernet, QoS, encryption transmission, automatic configuration, new system, smooth operation, flat interface settings and many other advantages.

For enterprise users,while realizing environmental protection, they also provide convenient operation. Users can flexibly configure and define the functions of two DSS keys, space saving and cost. It will be an ideal choice for enterprise users and family users who pursue the high quality and high efficiency.

In order to help some interested users better understand the details of the product, this user manual can be used as a reference guide for the use of H5W series. This document may not be applicable to the latest version of the software. If you have any questions, you can use the help prompt interface of the device phone, or download and update your user manual from the official website.


4.2 H5W Packing Contents



IP Phone




Handset



Handset Cord



Ethernet Cable



Quick Installation Guide



Power Adapter
(Optional)


4.3 H3W Packing Contents



IP Phone



Handset



Handset Cord



Ethernet Cable



Quick Installation Guide



Power Adapter
(Optional)

5 Desktop Installation

5.1 PoE and the use of external power adapters

The devices support two power supply modes from external power adapter or over Ethernet (PoE) complied switch.


PoE power supply saves the space and cost of providing the device additional power outlet. With a PoE switch, the device can be powered through a single Ethernet cable which is also used for data transmission. By attaching UPS system to PoE switch, the device can keep working at power outage just like traditional PSTN telephone which is powered by the telephone line.

For users who do not have PoE equipment, the traditional power adaptor should be used. If the device is connected to a PoE switch and power adapter at the same time, the power adapter will be used in priority and will switch to PoE power supply once it fails.

Please use the power adapter supplied by Fanvil and the PoE switch met the specifications to ensure the device to work properly.


5.2 Desktop and wall mounted method

The device supports two installation modes, desktop and wall mounted. If the phone is on the desktop, please follow the instructions in the picture below to install the phone.




Picture 1 - Device installation

If the phone is mounted on the wall, please follow the instructions below to install it.



Picture 2 - Wall-mounted installation

Connect the power adapter, network, PC, phone and earphone to the appropriate port as shown in the picture below.



Picture 3 - Connecting to the Device

Table 1 - Hardware Interface Description

Index	Interface	Description
①	Power Interface	Connecting Power Adapter
②	Network Interface	Connecting to LAN or Internet
③	PC Port	Network Interface for Connecting Computer
④	Headset Interface	Connecting Headset
⑤	Receiver Interface	Connecting Microphone Receiver

6 Appendix Table

6.1 Appendix I - Icon

Table 2 - Keypad Icons

Icon	Instruction
	Redial
	MWI
	Hands-free (HF) speaker
	Mute Microphone (During Call)
	Volume down
	Volume up
	Hold
	Transfer

6.2 Appendix II - Keyboard character query table


Table 3 - Look-up Table of Characters

Mode Icon	Text Mode	Key Button	Characters Of Each Press
	Numeric		1
			2
			3
			4
			5
			6
			7
			8
			9
			0
			*.+
			#
	Lower Case Alphabets		@:;()<>
			a b c
			d e f
			g h i

		5	j k l
		6	m n o
		7	p q r s
		8	t u v
		9	w x y z
		0	(space)
		*	.,*/+:-_ =
		#	# ^!&\$%
	Upper Case Alphabets	1	@:;()<>
		2	A B C
		3	D E F
		4	G H I
		5	J K L
		6	M N O
		7	P Q R S
		8	T U V
		9	W Z Y X
		0	(space)
		*	.,*/+:-_ =
		#	# ^!&\$%
	Mixed type input	1	1
		2	2 a b c A B C
		3	3 d e f D E F
		4	4 g h I G H I
		5	5 j k l J K L
		6	6 m n o M N O
		7	7 p q r s P Q R S
		8	8 t u v T U V
		9	9 w z y x W Z Y X
		0	0
		*	.,*/+:-_ =
		#	# ^!&\$%

7 Introduction to the User

7.1 H5W Key description




Picture 4 - H5W Instruction of Keypad

Table 4 - H5W Instruction of Keypad

Number	The keypad names	Instruction
①	Softkey	These six buttons provide the menu function that corresponds to the display on the screen
②	Standard Telephone Keys	The 12 standard telephone keys provide the same function as standard telephones, but further to the standard function, some keys also provide special function by long-pressing the key,

③	Hold Key	Press the "Hold" key during the call, the user can hold the call, and press it again to cancel the holding and restore the normal call state.
④	Transfer Key	Press the "Transfer" button, the user can transfer the current call to other numbers.
⑤	Redial	Press the Redial key to redial the last number dialed
⑥	voice mail	Press the "voice mail" button, and the user enters the interface of SMS and voice mail list.
⑦	Volume Down Key	In the standby state, ring and ring configuration interface, press this button to reduce the ring volume; Press this button to lower the volume on the call or volume adjustment screen.
⑧	Volume Up Key	In the standby state, ring and ring configuration interface, press this button to increase the ring volume; Press this button to increase the volume on the call or volume adjustment screen.
⑨	Mute Key	During a call, the user can press this key to mute the microphone.
⑩	Hands-free Key	The user can press this key to open the audio channel of the speakerphone.

7.2 H5W Key description



Picture 5 - H3W Instruction of Keypad

Table 5 - H3W Instruction of Keypad

Number	The keypad names	Instruction
①	Softkey	These six buttons provide the menu function that corresponds to the display on the screen
②	Standard Telephone Keys	The 12 standard telephone keys provide the same function as standard telephones, but further to the standard function, some keys also provide special function by long-pressing the key,
③	Hold Key	Press the "Hold" key during the call, the user can hold the call, and press it again to cancel the holding and restore the normal call state.
④	Transfer Key	Press the "Transfer" button, the user can transfer the current call to other numbers.

⑤	Redial	Press the Redial key to redial the last number dialed
⑥	voice mail	Press the "voice mail" button, and the user enters the interface of SMS and voice mail list.
⑦	Volume Down Key	In the standby state, ring and ring configuration interface, press this button to reduce the ring volume; Press this button to lower the volume on the call or volume adjustment screen.
⑧	Volume Up Key	In the standby state, ring and ring configuration interface, press this button to increase the ring volume; Press this button to increase the volume on the call or volume adjustment screen.
⑨	Mute Key	During a call, the user can press this key to mute the microphone.
⑩	Hands-free Key	The user can press this key to open the audio channel of the speakerphone.

7.3 Using Handset / Hands-free Speaker


■ Using Handset

About the use of the handle, the user can pick up the handle to dial the number, press the "#" button after pressing the number, the number will be dialed. Users can switch audio channels of the phone by pressing the hands-free button.

■ Using Hands-free Speaker

For the use of the speakerphone, the user can dial the number by pressing the speakerphone button, or by dialing the number and then pressing the speakerphone button. When the voice channel of the handle is opened, the user can switch the audio channel of the phone by pressing the button of the hands-free speaker.

7.4 Idle Screen



Picture 6 - Screen layout/default home screen

Users can restore the phone to the default standby screen interface by picking up and dropping the handle. The icon description is described in [6.1 appendix I](#).

In some screens, there are many items or long text to be displayed which could not fit into the screen. They will be arranged in a list or multiple lines with a scroll bar. If the user sees a scroll bar, he can use up/down navigator buttons to scroll the list. By long-pressed the navigator keys, user can scroll the list or items in a faster speed.



Picture 7 - Scroll icon

7.5 Phone Status

The phone status includes the following information about the phone:

- Network Status:

VLAN ID

IPv4 or IPv6 status

IP Address

Network Mode

- The Phone Device Information:

Mac Address

Phone Mode

Hardware Version number

Software Version number

Phone Storage (RAM and ROM)


System Running Time

- H3W phone: Long press the "#" key (more than 3 seconds) for voice dial IP
- H5W Phone interface: When the phone is in standby mode, long press the "#" key (more than 3 seconds) to enter the menu page and select the option to view the corresponding information.



Picture 8 - The Phone status

- WEB interface: Refer to [7.5 Web management](#) to log in the phone page, enter the **【System】** >> **【Information】** page, and check the phone status, as shown in the figure:



Picture 9 - WEB phone status

7.6 Making Phone Calls

■ Default Line

The device provides two line services (1 main line and 1 standby line). if both lines are configured successfully, the user uses line 1 to make or receive calls by default.

■ Dialing Methods

Users can dial a number in the following ways:

- The Device end
 - Dial directly, pick up the handle and input the number, then press "#" to call out
 - Redialing the last dialed number (Redial)


■ Dialing Number then Opening Audio

To make a phone call, user can firstly dial a number by one of the above methods. When the dialed number is completed, user can press [Dial] button on the soft-menu, or press hand-free button to turn on the speaker or headphone, or lift the handset to call out with the current line.

■ Opening Audio then Dialing the Number

Another alternative is the traditional way to firstly open the audio channel by lifting the handset, then turn on


the hands-free speaker by pressing hands-free button, or line key, and then dial the number with one of the above methods. When completing the number dial, user can press **[Dial]** button to call out, or the number can also be dialed out automatically after timeout.



Picture 10 - Open the voice channel and dial the number

■ Cancel Call

While calling the number, user can stop the audio channel by putting back the handset or pressing the hands-free button to drop the call.



Picture 11 - Call number

7.7 Web Management

Phone can be configured and managed on the web page of the phone. The user needs to enter the IP address of the phone in the browser and open the web page of the phone firstly. H5W users can access the menu page and check the IP address of their phone by pressing the "#" key for more than 3 seconds. H3W users can voice dial the phone's IP address by long pressing the "#" key (3 seconds or more).



Picture 12 - Landing page

Users must correctly enter the user name and password to log in to the web page. The default user name and password are "admin". For the specific details of the operation page, please refer to page [11 Web configuration](#).

The device relies on IP network connection to provide service. Unlike traditional phone system based on a circuit switched wire technology, IP devices are connected to each other over the network and exchange data in packet basis based on the devices' IP address.

NOTICE! If user saw a  'WAN Disconnected' icon flashing in the middle of screen, it means the network cable was not correctly connected to the device's network port. Please check the cable is connected correctly to the device and to the network switch, router, or modem.

The device supports three types of networks, IPv4/IPv6/IPv4&IPv6

There are three common IP configuration modes about IPv4

- Dynamic Host Configuration Protocol (DHCP) – This is the automatic configuration mode by getting network configurations from a DHCP server. Users don't need to configure any parameters manually. All configuration parameters will be getting from DHCP server and applied to the device. This is recommended for the most users.
- Static IP Configuration – This option allows user to configure each IP parameters manually, including IP Address, Subnet Mask, Default Gateway, and DNS servers. This is usually used in a technical environment of network users.
- PPPoE - This option is often used by users who connect the device to a broadband modem or router. To establish a PPPoE connection, user should configure username and password provided by the service provider.

The device is default configured in DHCP mode.

There are three common IP configuration modes about IPv6

- DHCP - This is the automatic configuration mode by getting network configurations from a DHCP server. Users need not to configure any parameters manually. All configuration parameters will be getting from DHCP server and applied to the device. This is recommended for most users.
- Static IP configuration - this option allows users to manually configure each IP parameter, including IP address, mask, gateway, and primary and secondary domains. This usually applies to some


professional network user environments.

Please see [10.7.2.1 network Settings](#) for detailed configuration and use.

7.8 SIP Configurations

A line must be configured properly to be able to provide telephony service. The line configuration is like a virtualized SIM card on a mobile phone which stores the service provider and the account information used for registration and authentication. When the device is applied with the configuration, it will register the device to the service provider with the server's address and user's authentication as stored in the configurations. The user can conduct line configuration on the interface of the phone or the webpage, and input the corresponding information at the registered address, registered user name, registered password and SIP user and registered port respectively, which are provided by the SIP server administrator.

- WEB interface: After logging into the phone page, enter **[Line]** >> **[SIP]** and select **SIP** for configuration, click apply to complete registration after configuration, as shown below:



Line 32@SIP1

Register Settings >>

Line Status: **Registered**

Username:

Display name:

Realm:

Activate: ☒

Authentication User:

Authentication Password:

Server Name:

SIP Server 1:

Server Address:

Server Port:

Transport Protocol: UDP

Registration Expiration: second(s)

Proxy Server Address:

Proxy Server Port:

Proxy User:

Proxy Password:

SIP Server 2:

Server Address:

Server Port:

Transport Protocol: UDP

Registration Expiration: second(s)

Backup Proxy Server Address:


Backup Proxy Server Port:

Picture 13 - Web SIP registration

8 Basic Function

8.1 Answering Calls

When there is an incoming call while the device is idle, user will see the following incoming call on the screen.




Picture 14 - Answering calls

User can answer the call by lifting the handset, open speaker phone by pressing the hands-free button, or the [Answer] button. To divert the incoming call, user should press [Divert] button. To reject the incoming call, user should press [Reject] button.

8.1.1 Talking

When the call is connected, user will see a talking mode screen as the following figure.



Picture 15 - Talking interface

Table 5- Talking mode


Number	Name	Description
①	Default line	The line currently used by the phone.
②	Voice channel	The icon shows the voice channel mode being used.
③	Calls to end	The name or number of the person on the other end of the call.
④	Call duration	The duration of a call after it has been established.
⑤	Numbers of line	Shows how many calls are present on the current device
⑥	Speech quality	Displays the current voice quality of the call.

8.1.2 Make / Receive Second Call

The device can support up to two concurrent calls. When there is already a call established, user can still answer another incoming call on either lines or make a second call on either lines.

■ Second Incoming Call


When there is another incoming call during talking a phone call, this call will be waiting for user to answer. User will see the call message in the middle of current screen. The device will not be ringing but playing call waiting tone in the audio channel of the current call and the LED will be flashing in green. User can accept or reject the call as same as normal incoming call. When the waiting call is answered, the first call will be held on automatically.



Picture 16 - The second call interface

■ Switching between Two Calls

When there are two calls established, user will see a dual calls screen as the following picture.



Picture 17 - Two way calling

User can press up/down navigator buttons to switch screen page, and switch call focus by pressing [**Resume**] button.

■ Ending One Call

User may hang up the current talking call by closing the audio channel or press [**End**] button. The device will return to single call mode in holding state.

8.2 End of the Call

After the user finishes the call, the user can put the handle back on the phone, press the hands-free button to close the voice channel and end the call.

8.3 Redial

- Redial the last outgoing number:
When the phone is in standby mode, press the redial button and the phone will call out the last number dialed.
- Call out any number with the redial key:
Enter the number, press the redial key, and the phone will call out the number on the dial.
- Redial record clearing

After the phone is used, redial will default to the last used number; therefore, it is necessary to clear the records used by the last customer without affecting the use of other customers.

8.4 Auto-Answering

Users can enable the automatic answer function in the web page, the phone will be able to answer automatically after the call. Automatic response enables differentiated lines to be enabled.

- **WEB interface:**
Log in the phone page, enter [**Line**] >> [**SIP**], select [**SIP**] >> [**Basic settings**], start auto-answering, and

click apply after setting the automatic answering time.

Line: 32@SIP1

Register Settings >>

Basic Settings >>

Enable Auto Answering: ☐ ?

Auto Answering Delay: 5 (0~120)second(s) ?

Call Forward Unconditional: ☐ ?

Call Forward Number for Unconditional: ?

Call Forward on Busy: ☐ ?

Call Forward Number for Busy: ?

Call Forward on No Answer: ☐ ?

Call Forward Number for No Answer: ?

Call Forward Delay for No Answer: 5 (0~120)second(s) ?

Transfer Timeout: 0 second(s) ?

Picture 18 - Web page to start auto-answering


8.5 Mute

You can turn on mute mode during a call and turn off the microphone so that the local voice is not heard. Normally, mute mode is automatically turned off at the end of a call. You can also turn on mute on any screen (such as the free screen) and mute the ringtone automatically when there is an incoming call. Mute mode can be turned on in all call modes (handles or hands-free).

8.5.1 Mute the Call

- During the conversation, press the mute button on the phone: the mute button on the phone will turn on the red light.

Red mute icon is displayed in the call interface, as shown in the figure:




Picture 19 - Mute the call

- Cancel mute: press cancel mute on the phone again. The mute icon is no longer displayed in the call screen. The red light is off by mute button.

8.5.2 Ringing Mute

- Mute: press the mute button when the phone is in standby mode:

The top right corner of the phone shows the bell mute icon  , Mute button red light is always on, when there is an incoming call, the phone will display the incoming call interface but will not ring.




Picture 20 - Ringing mute

- Cancel ring tone mute: On the standby or incoming call screen, press the mute button again  or volume up  cancel ring tone mute, no longer shows mute icon in upper right corner after cancel  .The phone mute icon is off .

8.6 Call Hold/Resume

The user can press the [**Hold**] button to maintain the current call, and this button will become the [**Resume**] button, and the user can press the "resume" button to restore the call.




Picture 21 - Call hold interface

8.7 Call Transfer

When the user is talking with a remote party and wish to transfer the call to another remote party.

During the call, the user presses transfer button on the phone  , Enter the number to transfer or press the contact button or the history button to select the number, press the transfer key again or blind transfer  to a third party. After the third party rings, the phone will show that the transfer is successful and hang up.




Picture 22 - Transfer interface

8.8 Call Waiting

- Enable call waiting: new calls can be accepted during a call.
- Disable call waiting: new calls will be automatically rejected and a busy tone will be prompted.
- Enable call waiting tone: when you receive a new call on the line, the tone will beep.
- The user can enable/disable the call waiting function in the phone interface and the web interface.

WEB interface: Enter [**Phone Settings**] >> [**Features**] >> [**Basic Settings**], enable/disable call waiting and call waiting tone.



Picture 23 - Web call waiting setting

Basic Settings >>

Tone Settings >>

Enable Holding Tone:	☒ ?	Enable Call Waiting Tone:	☒ ?
Play Dialing DTMF Tone:	☒ ?	Play Talking DTMF Tone:	☒ ?

Picture 24 - Web call waiting tone setting

8.9 Anonymous Call

8.9.1 Anonymous Call

The phone can set up anonymous calls to hide the calling number and the calling name.

- On the web page [Line] >> [SIP] >> [Advanced Settings] can also open the mode of anonymous calls.
- Setting to enable anonymous calls also corresponds to the SIP line. That is, the setting under the SIP1 page can only take effect on the SIP1 line.

User Agent:	?	Specific Server Type:	COMMON ?
SIP Version:	RFC3261 ?	Anonymous Call Standard:	None ?
Local Port:	5060 ?	Ring Type:	None ?
Enable user=phone:	☐ ?	Use Tel Call:	RFC3323
Auto TCP:	☐ ?	Enable PRACK:	RFC3325
Enable Rport:	☒ ?		

Picture 25 - Enable Anonymous web page call

8.9.2 Ban Anonymous Call

The device can be set to prohibit anonymous calls, that is anonymous calls to the number will be directly rejected.

- On the web page [Line] >> [SIP] >> [Advanced Settings], also can disable anonymous calls.
- The setup to disable anonymous calls also corresponds to the SIP line. That is, the setting under the SIP1 page can only take effect on the SIP1 line.


Enable Session Timer:	☐ ?	Session Timeout:	0 second(s) ?
Response Single Codec:	☐ ?	Keep Alive Interval:	15 second(s) ?
Keep Alive Type:	UDP ?	Blocking Anonymous Call:	☐ ?
Keep Authentication:	☐ ?		
RTP Encryption(SRTP):	Disabled ?		

Picture 26 - Page Settings blocking anonymous call

8.10 Hotline

The device supports hotline dialing. After setting up the hotline dialing, directly pick up the handset, hands-free etc., and the phone will automatically call according to the hotline delay time.

- On the website [Line] >> [SIP] >> [Basic Settings], can also set up a hotline.
- The setup hotline also corresponds to the SIP line. That is, the hotline set in the SIP1 webpage can only be activated in the SIP1 line.



The screenshot displays the 'Basic Settings' page for a SIP line. The 'Hotline' configuration section is highlighted with a red rectangular box. This section includes the following fields:

- Enable Hotline:** A checkbox that is currently unchecked.
- Hotline Number:** An empty text input field.

Other visible settings on the page include:

- Subscribe For Voice Message:** An unchecked checkbox.
- Voice Message:** A text input field containing '3600'.
- Subscribe Period:** A text input field containing '(60~999999)second(s)'.
- Hotline Delay:** A text input field containing '0' with a unit of '(0~9)second(s)'.
- Dial Without Registered:** An unchecked checkbox.
- DTMF Type:** A dropdown menu set to 'AUTO'.
- Request With Port:** A checked checkbox.
- Use STUN:** An unchecked checkbox.
- Voice Message Number:** An empty text input field.
- Enable Missed Call Log:** A checked checkbox.
- DTMF SIP INFO Mode:** A dropdown menu set to 'Send 10/11'.
- Use VPN:** A checked checkbox.

Picture 27 - Hotline set up on webpage

9 Advance Function

9.1 MCAST

This feature allows user to make some kind of broadcast call to people who are in multicast group. User can configure a multicast DSS Key on the phone, which allows user to send a Real Time Transport Protocol (RTP) stream to the pre-configured multicast address without involving SIP signaling. You can also configure the phone to receive an RTP stream from pre-configured multicast listening address without involving SIP signaling. You can specify up to 10 multicast listening addresses.

9.2 MWI (Message Waiting Indicator)

If the service of the lines supports voice message feature, when the user is not available to answer the call, the caller can leave a voice message on the server to the user. The user will be notified of the server voice message and the status of the power lamp.

To listen to a voice message, the user must first configure the voicemail number. After the voicemail number is configured, the user can retrieve the voicemail of the default line.

10 Web Configurations

10.1 Web Page Authentication

The user can log into the web page of the phone to manage the user's phone information and operate the phone. Users must provide the correct user name and password to log in.

10.2 System >> Information

User can get the system information of the device in this page including,

- Model
- Hardware Version
- Software Version
- Uptime

And summarization of network status,

- Network Mode
- MAC Address
- IP
- Subnet Mask
- Default Gateway

Besides, summarization of SIP account status,

- SIP User
- SIP account status (Registered / Unapplied / Trying / Timeout)

10.3 System >> Account

On this page the user can change the password for the login page.

Users with administrator rights can also add or delete users, manage users, and set permissions and passwords for new users.

10.4 System >> Configurations

On this page, users with administrator privileges can view, export, or import the phone configuration, or restore the phone to factory Settings.

■ Clear Configurations

Select the module in the configuration file to clear.

SIP: account configuration.

AUTOPROVISION: automatically upgrades the configuration

TR069:TR069 related configuration

MMI: MMI module, including authentication user information, web access protocol, etc.

DSS Key: DSS Key configuration

■ Clear Data Tables

Select the local data table to be cleared, all selected by default.

■ Reset Phone

The phone data will be cleared, including configuration and database tables.

10.5 System >> Upgrade

10.5.1 H5W System >> Upgrade

Upgrade phone software version, custom ring tone, background image, DSS Key icon, etc., or delete the upgrade file. Ringtone support. Wav format

- Web page: Login phone web page, go to **[System] >> [Upgrade]**.

Software upgrade ?

Current Software Version: 2.3.0

System Image File:

Upgrade Server

Enable Auto Upgrade: ☐

Upgrade Server Address1:

Upgrade Server Address2:

Update Interval: hour

Firmware Information

Current Software Version: 2.3.0

Server Firmware Version:

New Firmware Information:

Ring Upgrade ?

Load Server File: (*.wav)

Ring List ?

Index	File Name	File Size
☐		Delete

Background Upgrade ?

Load Server File: (*.bmp)

Background List ?

Index	File Name	File Size
☐		Delete

DSS Key Icons Upgrade ?

Load Server File: (*.png,*.tar.gz)

DSS Key Icons List ?

Index	File Name	File Size
☐		Delete

Picture 28 - H5W Web page firmware upgrade

10.5.2 H3W System >> Upgrade

Upgrade the phone software version, customize the ringtone, or delete the upgrade file. Ringtone support. Wav format.

- Web page: Login phone web page, go to **[System] >> [Upgrade]**.

Software upgrade

Current Software Version: 2.3.0

System Image File:

Select

Upgrade

Upgrade Server

Enable Auto Upgrade:
☐

Upgrade Server Address1:

Upgrade Server Address2:

Update Interval: 24 hour

Apply

Firmware Information

Current Software Version: 2.3.0T

Server Firmware Version: Checking

Upgrade

New Firmware Information:

Ring Upgrade

Load Server File:

Select

(* .wav) Upload

Ring List

Index	File Name	File Size
☐		Delete

Picture 29 - Picture 28 - H3W Web page firmware upgrade

Table 6 - Firmware upgrade

Parameter	Description
Upgrade server	
Enable Auto Upgrade	Enable automatic upgrade, If there is a new version txt and new software firmware on the server, phone will show a prompt upgrade message after Update Interval.
Upgrade Server Address1	Set available upgrade server address.
Upgrade Server Address2	Set available upgrade server address.
Update Interval	Set Update Interval.
Firmware Information	
Current Software Version	It will show Current Software Version.
Server Firmware Version	It will show Server Firmware Version.
[Upgrade] button	If there is a new version txt and new software firmware on the server, the page will display version information and upgrade button will become available; Click [Upgrade] button to upgrade the new

	firmware.
New version description information	When there is a corresponding TXT file and version on the server side, the TXT and version information will be displayed under the new version description information.

- The file requested from the server is a TXT file called vendor_model_hw10.txt. Hw followed by the hardware version number, it will be written as hw10 if no difference on hardware. All Spaces in the filename are replaced by underline.
- The URL requested by the phone is HTTP:// server address/vendor_Model_hw10.txt: The new version and the requested file should be placed in the download directory of the HTTP server
- TXT file format must be UTF-8
- vendor_model_hw10.TXT The file format is as follows:
Version=1.6.3 #Firmware
Firmware=xxx/xxx.z #URL, Relative paths are supported and absolute paths are possible, distinguished by the presence of protocol headers.
BuildTime=2018.09.11 20:00
Info=TXT|XML
Xxxxx
Xxxxx
Xxxxx
Xxxxx
- After the interval of update cycle arrives, if the server has available files and versions, the phone will prompt as shown below. Click [view] to check the version information and upgrade.

10.6 System >> Auto Provision

Phone Webpage: Login and go to **[System]** >> **[Auto provision]**.

Basic Settings

CPE Serial Number:00100400FV02001000000c383e466637

Authentication Name:

Authentication Password:

Configuration File Encryption Key:

General Configuration File Encryption Key:

Download Fail Check Times:1

Save Auto Provision Information:

Download CommonConfig enabled:

Enable Server Digest:

Display Provision Prompt:Disable All Provision Prompt

?

?

?

?

?

?

?

?

DHCP Option >>

DHCPv6 Option >>

SIP Plug and Play (PnP) >>

Static Provisioning Server >>

Autoprovision Now >>

TR069 >>

Apply

Picture 30 - Page auto provision Settings

Fanvil devices support SIP PnP, DHCP options, Static provision, TR069. If all of the 4 methods are enabled, the priority from high to low as below:

PNP>DHCP>TR069> Static Provisioning

Transferring protocol: FTP, TFTP, HTTP, HTTPS

Details refer to **Fanvil Auto Provision in**

<http://www.fanvil.com/Uploads/Temp/download/20180920/5ba3816f8d5f0.pdf>

Table 7 - Auto Provision

Parameters	Description
Basic settings	
CPE Serial Number	Display the device SN
Authentication Name	The user name of provision server
Authentication Password	The password of provision server
Configuration File Encryption Key	If the device configuration file is encrypted , user should add the encryption key here
General Configuration File Encryption Key	If the common configuration file is encrypted, user should add the encryption key here
Download Fail Check Times	If there download is failed, phone will retry with the configured times.

Update Contact Interval	Phone will update the phonebook with the configured interval time. If it is 0, the feature is disabled.
Save Auto Provision Information	Save the HTTP/HTTPS/FTP user name and password. If the provision URL is kept, the information will be kept.
Download Common Config enabled	Whether phone will download the common configuration file.
Enable Server Digest	When the feature is enable, if the configuration of server is changed, phone will download and update.
DHCP Option	
Option Value	Configure DHCP option, DHCP option supports DHCP custom option DHCP option 66 DHCP option 43, 3 methods to get the provision URL. The default is Option 66.
Custom Option Value	Custom Option value is allowed from 128 to 254. The option value must be same as server define.
Enable DHCP Option 120	Use Option120 to get the SIP server address from DHCP server.
SIP Plug and Play (PnP)	
Enable SIP PnP	Whether enable PnP or not. If PnP is enable, phone will send a SIP SUBSCRIBE message with broadcast method. Any server can support the feature will respond and send a Notify with URL to phone. Phone could get the configuration file with the URL.
Server Address	Broadcast address. As default, it is 224.0.0.0.
Server Port	PnP port
Transport Protocol	PnP protocol, TCP or UDP.
Update Interval	PnP message interval.
Static Provisioning Server	
Server Address	Provisioning server address. Support both IP address and domain address.
Configuration File Name	The configuration file name. If it is empty, phone will request the common file and device file which is named as its MAC address. The file name could be a common name, \$mac.cfg, \$input.cfg. The file format supports CFG/TXT/XML.
Protocol Type	Transferring protocol type , supports FTP、TFTP、HTTP and HTTPS
Update Interval	Configuration file update interval time. As default it is 1, means phone will check the update every 1 hour.
Update Mode	Provision Mode. 1. Disabled. 2. Update after reboot. 3. Update after interval.
TR069	

Enable TR069	Enable TR069 after selection
ACS Server Type	There are 2 options Serve type, common and CTC.
ACS Server URL	ACS server address
ACS User	ACS server username (up to is 59 character)
ACS Password	ACS server password (up to is 59 character)
Enable TR069 Warning Tone	If TR069 is enabled, there will be a prompt tone when connecting.
TLS Version	TLS version (TLS 1.0, TLS 1.1, TLS 1.2)
INFORM Sending Period	INFORM signal interval time. It ranges from 1s to 999s
STUN Server Address	Configure STUN server address
STUN Enable	To enable STUN server for TR069

10.7 System >> Tools

Tools provided in this page help users to identify issues at trouble shooting. Please refer to [13 Trouble Shooting](#) for more detail.

10.8 System >> Reboot Phone

This page can restart the phone.

11 Network

This page allows users to configure network connection types and parameters.


11.1 Network >> Wi-Fi Settings

The default network priority is WiFi

The current device supports coexistence of wifi and Ethernet, and users can log in to the web page with any network address for configuration

For example, WiFi access IP is 172.16.19.19 and Ethernet access IP is 172.16.12.63


Page login 172.16.12.63, 172.16.19.19 Any network address login page for configuration



The screenshot displays the Fanvil web interface for network configuration. The left sidebar contains a menu with options: System, Network, Line, Phone settings, Phonebook, Call logs, Function Key, Application, Security, and Device Log. The main content area has tabs for Basic, Wi-Fi Settings, Service Port, VPN, and Advanced. The 'Wi-Fi Settings' tab is active. Within this tab, the 'Net Global' section is highlighted with a red box, showing 'Network Priority' set to 'Wi-Fi' with an 'Apply' button. Below this, 'Net Type' is set to 'Ethernet'. The 'Network Mode' is set to 'IPv4 Only'. The 'IPv4 Network Status' section lists the following details: IP: 172.16.12.226, Subnet mask: 255.255.255.0, Default gateway: 172.16.19.1, and MAC: 0c:38:3e:46:1d:ae. The 'IPv4 Settings' section at the bottom shows 'Static IP' selected, 'Enable Vendor Identifier' set to 'Disabled', 'Vendor Identifier' set to 'Fanvil X3V', 'DNS Server Configured by' set to 'DHCP', 'Primary DNS Server' set to '223.5.5.5', 'Secondary DNS Server' set to '114.114.114.114', and 'DNS Domain' is empty.

Picture 31 - Network Priority

This page can turn on WiFi, add WiFi information, and view the wireless network list.



Picture 32 - WiFi Settings

11.2 Network >> Basic

■ IP Mode

There are 3 network protocol mode options, IPv4, IPv6 and IPv4 & IPv6.

■ IPv4

In IPv4 mode, there are 3 connection mode options: DHCP, PPPoE and Static IP.

When using DHCP mode, phone will get the IP address from DHCP server (router).

- Use DHCP DNS: It is enabled as default. “Enable” means phone will get DNS address from DHCP server and “disable” means not.
- Use DHCP time: It is disabled as default. “Enable” to manage the time of get DNS address from DHCP server and “disable” means not

When using PPPoE, phone will get the IP address from PPPoE server.

- Username: PPPoE user name.
- Password: PPPoE password.

When using Static IP mode, user must configure the IP address manually.

- IP Address: Phone IP address.
- Mask: sub mask of your LAN.
- Gateway: The gateway IP address. Phone could access the other network via it.
- Primary DNS: Primary DNS address. The default is 8.8.8.8, Google DNS server address.
- Secondary DNS: When primary DNS is not available, Secondary DNS will work.

■ IPv6

In IPv6, there are 2 connection mode options, DHCP and Static IP.

- DHCP configuration refers to IPv4 introduction in last page.
- Static IP configuration is almost same as IPv4's, except the IPv6 Prefix.
- IPv6 Prefix: IPv6 prefix, it is similar with mask of IPv4.

11.3 Network >> Service Port

This page provides settings for Web page login protocol, protocol port settings and RTP port.

Picture 33 - Service Port Settings

Table 8 - Service port

Parameter	Description
Web Server Type	Reboot to take effect after settings. Optionally, the web page login is HTTP/HTTPS.
Web Logon Timeout	Default as 15 minutes, the timeout will automatically exit the login page, need to login again.
Web auto login	After the timeout does not need to enter a user name password, will automatically login to the web page.
HTTP Port	The default is 80. If you want system security, you can set ports other than 80. Such as :8080, webpage login: HTTP://ip:8080
HTTPS Port	The default is 443, the same as the HTTP port.
RTP Port Range Start	The value range is 1025 to 65535. The value of RTP port starts from the initial value set. For each call, the value of voice and video port is added 2.
RTP Port Quantity	Number of calls.

11.4 Network >> VPN

Virtual Private Network (VPN) is a technology to allow device to create a tunneling connection to a server and becomes part of the server's network. The network transmission of the device may be routed through the VPN server.

For some users, especially enterprise users, a VPN connection might be required to be established before activate a line registration. The device supports two VPN modes, Layer 2 Transportation Protocol (L2TP) and OpenVPN.

The VPN connection must be configured and started (or stopped) from the device web portal.

■ L2TP

NOTICE! The device only supports non-encrypted basic authentication and non-encrypted data tunneling. For users who need data encryption, please use OpenVPN instead.

To establish a L2TP connection, users should log in to the device web portal, open webpage **[Network] >> [VPN]**. In VPN Mode, check the "Enable VPN" option and select "L2TP", then fill in the L2TP server address, Authentication Username, and Authentication Password in the L2TP section. Press "Apply" then the device will try to connect to the L2TP server.

When the VPN connection established, the VPN IP Address should be displayed in the VPN status. There may be the delay of the connection establishment. User may need to refresh the page to update the status. Once the VPN is configured, the device will try to connect with the VPN automatically when the device boots up every time until user disable it. Sometimes, if the VPN connection does not establish immediately, user may try to reboot the device and check if VPN connection established after reboot.

■ OpenVPN

To establish an OpenVPN connection, user should get the following authentication and configuration files from the OpenVPN hosting provider and name them as the following,

OpenVPN Configuration file:	client.ovpn
CA Root Certification:	ca.crt
Client Certification:	client.crt
Client Key:	client.key

User then upload these files to the device in the web page **[Network] >> [VPN]**, select OpenVPN Files. Then user should check "Enable VPN" and select "OpenVPN" in VPN Mode and click "Apply" to enable OpenVPN connection.

Same as L2TP connection, the connection will be established every time when system rebooted until user disable it manually.

11.5 Network >> Advanced

■ LLDP

Link Layer Discovery Protocol. LLDP is a vendor independent link layer protocol used by network devices for

advertising their identity, capabilities to neighbors on a LAN segment.

Phone could use LLDP to find the VLAN switch or other VLAN devices and use LLDP learn feature to apply the VLAN ID from VLAN switch to phone its self.

■ CDP

Cisco Discovery Protocol. CDP is a not-for-profit charity that runs the global disclosure system for investors, companies, cities, states and regions to manage their environmental impacts. According to the CDP, Cisco devices could share the OS version, IP address, hardware version and so on.

Table 9 - QoS & VLAN

Parameters	Description
LLDP setting	
Report	Enable LLDP
Interval	LLDP requests interval time
Learning	apply the learned VLAN ID to the phone configuration
QoS	
QoS Mode	configure SIP DSCP and audio DSCP
WAN VLAN	
WAN VLAN	WAN port VLAN configuration
LAN VLAN	
LAN VLAN	LAN port VLAN configuration
CDP	
CDP	CDP enable/disable , CDP interval time

11.6 Line >> SIP

Configure the Line service configuration on this page.

Table 10 - Line configuration on the web page

Parameters	Description
Register Settings	
Line Status	Display the current line status at page loading. To get the up to date line status, user has to refresh the page manually.
Activate	Whether the service of the line is activated
Username	Enter the username of the service account.
Authentication User	Enter the authentication user of the service account
Display Name	Enter the display name to be sent in a call request.
Authentication Password	Enter the authentication password of the service account

Realm	Enter the SIP domain if requested by the service provider
Server Name	Input server name.
SIP Server 1	
Server Address	Enter the IP or FQDN address of the SIP server
Server Port	Enter the SIP server port, default is 5060
Transport Protocol	Set up the SIP transport line using TCP or UDP or TLS.
Registration Expiration	Set SIP expiration date.
SIP Server 2	
Server Address	Enter the IP or FQDN address of the SIP server
Server Port	Enter the SIP server port, default is 5060
Transport Protocol	Set up the SIP transport line using TCP or UDP or TLS.
Registration Expiration	Set SIP expiration date.
SIP Proxy Server Address	Enter the IP or FQDN address of the SIP proxy server.
Proxy Server Port	Enter the SIP proxy server port, default is 5060.
Proxy User	Enter the SIP proxy user.
Proxy Password	Enter the SIP proxy password.
Backup Proxy Server Address	Enter the IP or FQDN address of the backup proxy server.
Backup Proxy Server Port	Enter the backup proxy server port, default is 5060.
Basic Settings	
Enable Auto Answering	Enable auto-answering, the incoming calls will be answered automatically after the delay time
Auto Answering Delay	Set the delay for incoming call before the system automatically answered it
Call Forward Unconditional	Enable unconditional call forward, all incoming calls will be forwarded to the number specified in the next field
Call Forward Number for Unconditional	Set the number of unconditional call forward
Call Forward on Busy	Enable call forward on busy, when the phone is busy, any incoming call will be forwarded to the number specified in the next field.
Call Forward Number for Busy	Set the number of call forward on busy .
Call Forward on No Answer	Enable call forward on no answer, when an incoming call is not answered within the configured delay time, the call will be forwarded to the number specified in the next field.
Call Forward Number for No Answer	Set the number of call forward on no answer.
Call Forward Delay for No	Set the delay time of not answered call before being forwarded.

Answer	
Transfer Timeout	Set the timeout of call transfer process.
Server Conference Number	Set the conference room number when conference type is set to be Server
Subscribe For Voice Message	Enable the device to subscribe a voice message waiting notification, if enabled, the device will receive notification from the server if there is voice message waiting on the server
Voice Message Number	Set the number for retrieving voice message
Voice Message Subscribe Period	Set the interval of voice message notification subscription
Enable Hotline	Enabling hotline configuration, the device will dial to the specific number immediately at audio channel opened by off-hook handset or turn on hands-free speaker
Hotline Delay	Set the delay for hotline before the system automatically dialed it
Hotline Number	Set the hotline dialing number
Dial Without Registered	Set call out by proxy without registration
Enable Missed Call Log	If enabled, the phone will save missed calls into the call history record.
DTMF Type	Set the DTMF type to be used for the line
DTMF SIP INFO Mode	Set the SIP INFO mode to send '*' and '#' or '10' and '11'
Subscribe For Voice Message	Enable the device to subscribe a voice message waiting notification, if enabled, the device will receive notification from the server if there is voice message waiting on the server
Use VPN	Set the line to use VPN restrict route
Use STUN	Set the line to use STUN for NAT traversal
Enable Failback	Whether to switch to the primary server when it is available.
Failback Interval	A Register message is used to periodically detect the time interval for the availability of the main Proxy.
Signal Failback	Multiple proxy cases, whether to allow the invite/register request to also execute failback.
Signal Retry Counts	The number of attempts that the SIP Request considers proxy unavailable under multiple proxy scenarios.
Codecs Settings	Set the priority and availability of the codecs by adding or remove them from the list.
Video Codecs	Select video code to preview video.
Advanced Settings	
Use Feature Code	When this setting is enabled, the features in this section will not be handled by the device itself but by the server instead. In order to control the

	enabling of the features, the device will send feature code to the server by dialing the number specified in each feature code field.
Enable Call Forward Unconditional	Set the feature code to dial to the server
Disable Call Forward Unconditional	Set the feature code to dial to the server
Enable Call Forward on Busy	Set the feature code to dial to the server
Disable Call Forward on Busy	Set the feature code to dial to the server
Enable Call Forward on No Answer	Set the feature code to dial to the server
Disable Call Forward on No Answer	Set the feature code to dial to the server
Enable Blocking Anonymous Call	Set the feature code to dial to the server
Disable Blocking Anonymous Call	Set the feature code to dial to the server
Call Waiting On Code	Set the feature code to dial to the server
Call Waiting Off Code	Set the feature code to dial to the server
Send Anonymous On Code	Set the feature code to dial to the server
Send Anonymous Off Code	Set the feature code to dial to the server
SIP Encryption	Enable SIP encryption such that SIP transmission will be encrypted
RTP Encryption	Enable RTP encryption such that RTP transmission will be encrypted
Session Timeout	Set the session timer timeout period
Response Single Codec	If setting enabled, the device will use single codec in response to an incoming call request
BLF Server	The registered server will receive the subscription package from ordinary application of BLF phone. Please enter the BLF server, if the sever does not support subscription package, the registered server and subscription server will be separated.
Keep Alive Type	Set the line to use dummy UDP or SIP OPTION packet to keep NAT pinhole opened
Keep Alive Interval	Set the keep alive packet transmitting interval
Keep Authentication	Keep the authentication parameters from previous authentication
Blocking Anonymous Call	Reject any incoming call without presenting caller ID

User Agent	Set the user agent, the default is Model with Software Version.
Specific Server Type	Set the line to collaborate with specific server type
SIP Version	Set the SIP version
Anonymous Call Standard	Set the standard to be used for anonymous
Local Port	Set the local port
Ring Type	Set the ring tone type for the line
Enable user=phone	Sets user=phone in SIP messages.
Use Tel Call	Set use tel call
Auto TCP	Using TCP protocol to guarantee usability of transport for SIP messages above 1500 bytes
Enable Rport	Set the line to add rport in SIP headers
Enable PRACK	Set the line to support PRACK SIP message
DNS Mode	Select DNS mode, A, SRV, NAPTR
Enable Long Contact	Allow more parameters in contact field per RFC 3840
Enable Strict Proxy	Enables the use of strict routing. When the phone receives packets from the server, it will use the source IP address, not the address in via field.
Convert URI	Convert not digit and alphabet characters to %hh hex code
Use Quote in Display Name	Whether to add quote in display name, i.e. "Fanvil" vs Fanvil
Enable GRUU	Support Globally Routable User-Agent URI (GRUU)
Sync Clock Time	Time Sync with server
Enable Inactive Hold	With the post-call hold capture package enabled, you can see that in the INVITE package, SDP is inactive.
Caller ID Header	Set the Caller ID Header
Use 182 Response for Call waiting	Set the device to use 182 response code at call waiting response
Enable Feature Sync	Feature Sync with server
Enable SCA	Enable/Disable SCA (Shared Call Appearance)
CallPark Number	Set the CallPark number.
Server Expire	Set the timeout to use the server.
TLS Version	Choose TLS Version.
uaCSTA Number	Set uaCSTA Number.
Enable Click To Talk	With the use of special server, click to call out directly after enabling.
Flash mode	Chose Flash mode, normal or SIP info.
Flash Info Content-Type	Set the SIP info content type.
Flash Info Content-Body	Set the SIP info content body.
PickUp Number	Set the scramble number when the Pickup is enabled.

JoinCall Number	Set JoinCall Number.
Unregister On Boot	Whether to enable logout function.
Enable MAC Header	When opening the registration, are IP package and user agent with MAC.
Enable Register MAC Header	When opening the registration, is user agent with MAC.
BLF Dialog Strict Match	Whether to enable accurate matching of BLF sessions.
PTime(ms)	Set whether to bring ptime field, default no.
SIP Global Settings	
Strict Branch	Set up to strictly match the Branch field.
Enable Group	Set open group.
Enable RFC4475	Set to enable RFC4475.
Enable Strict UA Match	Enable strict UA matching.
Registration Failure Retry Time	Set the registration failure retry time.
Local SIP Port	Modify the phone SIP port.

11.7 Line >> SIP Hotspot

SIP hotspot is a simple but practical function. With simple configurations, the SIP hotspot function can implement group ringing. SIP accounts can be expanded.

The users can set functions as a SIP hotspot and other phones set (B and C) function as SIP hotspot clients. When somebody calls phone set A, phone sets A, B, and C all ring at the same time. When any phone set answers the call, other phone sets stop ringing. The call can be answered by only one phone set. When B or C initiates a call, the SIP number registered by phone set A is the calling number.

To set a SIP hotspot, register at least one SIP account.

Line
258@SIP1

Register Settings >>

Line Status: Registered

Username: 258

Display name: 258

Realm:

Activate: ☒

Authentication User: 258

Authentication Password:

Server Name:

SIP Server 1:

Server Address: 172.16.1.2

Server Port: 5060

Transport Protocol: UDP

Registration Expiration: 3600 second(s)

SIP Server 2:

Server Address:

Server Port: 5060

Transport Protocol: UDP

Registration Expiration: 3600 second(s)

Proxy Server Address:

Proxy Server Port: 5060

Proxy User:

Proxy Password:

Backup Proxy Server Address:

Backup Proxy Server Port: 5060

Picture 34 -SIP hotspot

Table 11 - SIP hotspot Parameters

Parameters	Description
Device Table	If your phone is set to “SIP hotspot server”, Device Table will display as Client Device Table which connected to your phone. If your phone is set to “SIP hotspot client”, Device Table will display as Server Device Table which you can connect to.
SIP hotspot	
Enable hotspot	Set it to be Enable to enable the feature.
Mode	Choose hotspot, phone will be a “SIP hotspot server”; Choose Client, phone will be a “SIP hotspot Client”
Monitor Type	Either the Multicast or Broadcast is ok. If you want to limit the broadcast packets, you’d better use broadcast. But, if client choose broadcast, the SIP hotspot phone must be broadcast.
Monitor Address	The address of broadcast, hotspot server and hotspot client must be same.
Remote Port	Type the Remote port number.

服务器端设置:

Client Table

IP	MAC	Alias	Line

SIP Hotspot Settings

Enable Hotspot:

Enabled ▾

?

Mode:

Hotspot ▾

?

Monitor Type:

Broadcast ▾

?

Monitor Address:

224.0.2.0

?

Local Port:

16360

?

Name:

SIP Hotspot

?

Ring Mode:

All ▾

Line Settings

Line 1:	Enabled ▾	Ext Prefix 1:	
Line 2:	Enabled ▾	Ext Prefix 2:	
Line 3:	Enabled ▾	Ext Prefix 3:	
Line 4:	Enabled ▾	Ext Prefix 4:	
Line 5:	Enabled ▾	Ext Prefix 5:	
Line 6:	Enabled ▾	Ext Prefix 6:	

Apply

Picture 35 - SIP hotspot server configuration

Configure SIP hotspot client:

To set as a SIP hotspot client, no SIP account needs to be set. The Phone set will automatically obtain and configure a SIP account. On the SIP Hotspot tab page, set Mode to Client. The values of other options are the same as those of the hotspot.

Hotspot Table

IP	Server name	Online Status	Connection Status	Alias	Line
----	-------------	---------------	-------------------	-------	------

SIP Hotspot Settings

Enable Hotspot:

Enabled ▾

?

Mode:

Client ▾

?

Monitor Type:

Broadcast ▾

?

Monitor Address:

224.0.2.0

?

Local Port:

16360

?

Name:

SIP Hotspot

?

Line Settings

Line 1:

Enabled ▾

Line 2:

Enabled ▾

Line 3:

Enabled ▾

Line 4:

Enabled ▾

Line 5:

Enabled ▾

Line 6:

Enabled ▾

Apply

Picture 36 - SIP hotspot client configuration

As the hotspot server, the default extension number is 0. When the phone is used as the client, the extension number is increased from 1, you can view the extension number through the **[SIP Hotspot]** page.

Call extension number:

- The hotspot server and the client can dial each other through the extension number.
- For example, extension 1 dials extension 0.

11.8 Line >> Dial Plan

Basic Settings

☒

Press # to invoke dialing

☐

Dial Fixed Length to Send

☒

Send after second(s)(3~30)

☐

Press # to Do Blind Transfer

☐

Blind Transfer on Onhook

☐

Attended Transfer on Onhook

☐

Attended Transfer on Conference Onhook

☐

Enable E.164

Apply

Picture 37 - Dial plan settings

Table 12 - Phone dialing methods

Parameters	Description
Press # to invoke dialing	The user dials the other party's number and then adds the # number to dial out;
Dial Fixed Length	The number entered by the user is automatically dialed out when it reaches a fixed length
Timeout dial	The system dials automatically after timeout
Press # to Do Blind Transfer	The user enters the number to be transferred and then presses the "#" key to transfer the current call to a third party
Blind Transfer on Onhook	After the user enters the number, hang up the handle or turn off the hands-free function to transfer the current call to a third party.
Attended Transfer on Onhook	Hang up the handle or press the hands-free button to realize the function of attention-transfer, which can transfer the current call to a third party.
Enable E.164	Please refer to e. 164 standard specification

添加拨号规则:

Dial Plan Add

Digit Map: ?

Apply to Call: Outgoing Call ?

Match to Send: No ?

Media: Default ?

Line: SIP DIALPEER ?

Destination: ?

Port: ?

Alias(Optional): No Alias ?

Phone Number: ?

Length: ?

Suffix: ?

Add

Dial Plan Option ?

▼
Delete
Modify

User-defined Dial Plan Table ?

Index	Digit Map	Call	Match to Send	Line	Alias Type: Number(length)	Suffix	Media
-------	-----------	------	---------------	------	----------------------------	--------	-------

Picture 38 - Custom setting of dial - up rules

Table 13 - Dial - up rule configuration table

Parameters	Description
Dial rule	There are two types of matching: Full Matching or Prefix Matching. In Full matching, the entire phone number is entered and then mapped per the Dial Peer rules. In prefix matching, only part of the number is entered followed by T. The mapping with then take place whenever these digits are dialed. Prefix mode supports a maximum of 30 digits.
Note: Two different special characters are used. ■ x -- Matches any single digit that is dialed. ■ [] -- Specifies a range of numbers to be matched. It may be a range, a list of ranges separated by commas, or a list of digits.	
Destination	Set Destination address. This is for IP direct.
Port	Set the Signal port, and the default is 5060 for SIP.
Alias	Set the Alias. This is the text to be added, replaced or deleted. It is an optional item.
Note: There are four types of aliases. ■ all: xxx – xxx will replace the phone number. ■ add: xxx – xxx will be dialed before any phone number. ■ del –The characters will be deleted from the phone number. ■ rep: xxx – xxx will be substituted for the specified characters.	
Suffix	Characters to be added at the end of the phone number. It is an optional item.
Length	Set the number of characters to be deleted. For example, if this is set to 3, the phone will delete the first 3 digits of the phone number. It is an optional item.

his feature allows the user to create rules to make dialing easier. There are several different options for dial rules. The examples below will show how this can be used.

Example 1: All Substitution -- Assume that it can make a direct IP call to IP address 172.168.2.208. Using this feature, 123 can be substituted for 172.168.2.208.



Index	Digit Map	Call	Match to Send	Line	Alias Type: Number(length)	Suffix	Media
1	"123"	Out	No	SIP DIALPEER(172.16.1.15:5560)			Default

Picture 39 - Dial rules table (1)

Example 2: Partial Substitution -- To dial a long distance call to Beijing requires dialing area code 010 before the local phone number. Using this feature 1 can be substituted for 010. For example, to call 62213123 would only require dialing 162213123 instead of 01062213123.

User-defined Dial Plan Table

Index	Digit Map	Call	Match to Send	Line	Alias Type: Number(length)	Suffix	Media
1	*1T	Out	No	Fanvil@SIP1	rep:010(1)		Default

Picture 40 - Dial rules table (2)

Example 3: Addition -- Two examples are shown. In the first case, it is assumed that 0 must be dialed before any 11 digit number beginning with 13. In the second case, it is assumed that 0 must be dialed before any 11 digit number beginning with 135, 136, 137, 138, or 139. Two different special characters are used.

x -- Matches any single digit that is dialed.

[] -- Specifies a range of numbers to be matched. It may be a range, a list of ranges separated by commas, or a list of digits.

11.9 Line >> Action Plan

1. When a IP phone calls a phone, the bound IP camera synchronously transmits video to the other phone (video is supported)
2. When SIP calls, multicast calls or intercom calls are made, the device converts calls that conform to the number rules into group calls.

Table 14 - IP camera

Parameter	Description
Number	Auxiliary phone number (support video)
Type	Support video display on call.
Direction	For call mode, incoming/outgoing call displays video
Line	Set up outgoing lines.
Username	Bind the user name of the IP camera.
Password	Bind IP camera password.
URL	Video streaming information;Mcast Address (mcast://IP:port)
User Agent	Set user agent information

Details refer to **Fanvil Action Plan**

11.10 Line >> Basic Settings

Set up the register global configuration.

Table 15 - Set the line global configuration on the web page

Parameters	Description
STUN Settings	
Server Address	Set the STUN server address
Server Port	Set the STUN server port, default is 3478
Binding Period	Set the STUN binding period which can be used to keep the NAT pinhole opened.
SIP Waiting Time	Set the timeout of STUN binding before sending SIP messages
The TLS authentication	
TLS Certification File	Upload or delete the TLS certification file used for encrypted SIP transmission.

11.11 Line >> RTCP-XR

RTCP-XR mode is based on RFC3611 (RTP Control Extended Report), which can measure and evaluate network packet loss, delay and voice quality by sending RTCP-XR packets.

Table 16 - VQ RTCP-XR Settings

Parameters	Description
VQ RTCP-XR Settings	
VQ RTCP-XR Session Report	VQ report on whether session mode is enabled or not.
VQ RTCP-XR Interval Report	Whether to turn on Interval mode for VQ report sending.
Period for Interval Report(5~99)	The time interval at which VQ reports are sent periodically.
Warning threshold for Moslq(15~40)	When the phone calculated the Moslq value x10 below the set threshold, a warning was issued.
Critical threshold for Moslq(15~40)	When the phone calculates the Moslq value x10 below the set threshold, the critical report is issued.
Warning Threshold for Delay(10~2000)	When the one-way delay of the phone is greater than the set threshold, warning is issued.
Critical Threshold for Delay(10~2000)	When the phone computes that the one-way delay is greater than the set threshold, the critical report is issued.
Display Report Options on web	Whether to display the VQ report data for the last call through the web page.

11.12 Phone settings >> Features

Configuration phone features.

Table 17 - General function Settings

Parameters	Description
Basic Settings	
Enable Call Waiting	Enable this setting to allow user to take second incoming call during an established call. Default enabled.
Enable Call Transfer	Enable Call Transfer.
Semi-Attended Transfer	Enable Semi-Attended Transfer by selecting it
Enable Auto Onhook	The phone will hang up and return to the idle automatically at hands-free mode
Auto Onhook Time	Specify Auto Onhook time, the phone will hang up and return to the idle automatically after Auto Hand down time at hands-free mode, and play dial tone Auto Onhook time at handset mode
Enable Silent Mode	When enabled, the phone is muted, there is no ringing when calls, you can use the volume keys and mute key to unmute.
Disable Mute for Ring	When it is enabled, you can't mute the phone
Enable Default Line	If enabled, user can assign default SIP line for dialing out rather than SIP1.
Enable Auto Switch Line	Enable phone to select an available SIP line as default automatically
Default Ext Line	Select the default line to use for outgoing calls
Ban Outgoing	If you select Ban Outgoing to enable it, and you cannot dial out any number.
Hide DTMF	Configure the hide DTMF mode.
Enable CallLog	Select whether to save the call log.
Enable Country Code	Whether the country code is enabled.
Country Code	Fill in the country code.
Area Code	Fill in the area code.
Enable Number Privacy	Whether to enable number privacy.
Match Direction	Matching direction, there are two kinds of rules from right to left and from left to right.
Start Position	Open number privacy after the start of the hidden location.
Hide Digits	Turn on number privacy to hide the number of digits.
Allow IP Call	If enabled, user can dial out with IP address
P2P IP Prefix	Prefix a point-to-point IP call.
Caller Name Priority	Change caller ID display priority.
Restrict Active URI Source IP	Set the device to accept Active URI command from specific IP address. More details please refer to this link http://www.fanvil.com/Uploads/Temp/download/20180920/5ba3641fe81a5.pdf .

Push XML Server	Configure the Push XML Server, when phone receives request, it will determine whether to display corresponding content on the phone which sent by the specified server or not.
Enable Pre-Dial	Disable this feature, user enter number will open audio channel automatically. Enable the feature, user enter the number without opening audio channel.
Enable Multi Line	If enabled, up to 10 simultaneous calls can exist on the phone, and if disabled, up to 2 simultaneous calls can exist on the phone.
Line Display Format	Custom line format: SIPn/SIPn: xxx/xxx@SIPn
Contact As White List Type	NONE/BOTH/DND White List/FWD White List
Block XML When Call	Disable XML push on call.
SIP notify	When enabled, the phone displays the information when it receives the relevant notify content.
Tone Settings	
Enable Holding Tone	When turned on, a tone plays when the call is held
Enable Call Waiting Tone	When turned on, a tone plays when call waiting
Play Dialing DTMF Tone	Play DTMF tone on the device when user pressed a phone digits at dialing, default enabled.
Play Talking DTMF Tone	Play DTMF tone on the device when user pressed a phone digits during taking, default enabled.
Response Code Settings	
Busy Response Code	Set the SIP response code on line busy
Reject Response Code	Set the SIP response code on call rejection
Password Dial Settings	
Enable Password Dial	Enable Password Dial by selecting it, When number entered is beginning with the password prefix, the following N numbers after the password prefix will be hidden as *, N stand for the value which you enter in the Password Length field. For example: you set the password prefix is 3, enter the Password Length is 2, then you enter the number 34567, it will display 3**67 on the phone.
Encryption Number Length	Configure the Encryption Number length
Password Dial Prefix	Configure the prefix of the password call number
Power LED	
Common	Standby power lamp state, off when off, open is always bright red. Off by default.
SMS/MWI	The status of power lamp when there is unread short message/voice message, including off/on/slow flash/quick flash, default slow flash.
Missed	The state of the power lamp when there is a missed call, including

	off/on/slow flash/quick flash, the default slow flash.
Talk/Dial	In the talk/dial state, the power lamp state, off is off, on is always red bright, the default is off.
Ringing	Power lamp status when there is an incoming call, including off/on/slow flash/quick flash, default flash.
Mute	Power lamp status in mute mode, including off/on/slow flash/quick flash, off by default.
Hold/Held	The power lamp state, including off/on/slow flash/quick flash, is turned off by default when left/retained.
Notification Popups	

11.13 Phone settings >> Media Settings

Change voice Settings.

Table 18 - Voice settings

Parameters	Description
Codecs Settings	Select enable or disable voice encoding: G.711A/U,G.722,G.729, G.726-16,G726-24,G726-32,G.726-40, ILBC, Opus
Audio Settings	
Handset Volume	Set the Handset volume, the value must be 1~9
Default Ring Type	Configure default ringtones. If no special ringtone is set for the phone number, the default ringtone will be used.
Speakerphone Volume	Set the hands-free volume to 1-9.
Speakerphone Ring Volume	Set the volume of hands-free ringtone to 1~9.
G.723.1 Bit Rate	5.3kb/s or 6.3kb/s is available.
DTMF Payload Type	Enter the DTMF payload type, the value must be 96~127.
AMR Payload Type	Set AMR load type, range 96~127.
Opus payload type	Set Opus load type, range 96~127.
OPUS Sample Rate	Set Opus sampling rate, including opus-nb (8KHz) and opus-wb (16KHz).
ILBC Payload Type	Set the ILBC Payload Type, the value must be 96~127.
ILBC Payload Length	Set the ILBC Payload Length
Enable MWI Tone	When there is a new voice message message, the phone will start a special dial tone.
Enable VAD	Whether voice activity detection is enabled.
Onhook Time	Configure a minimum response time, which defaults to 200ms
RTP Control Protocol(RTCP) Settings	

CNAME user	Set CNAME user
CNAME host	Set CNAME host
RTP Settings	
RTP keep alive	Hold the call and send the packet after 30s
Alert Info Ring Settings	
Value	Set the value to specify the ring type.
Ring Type	Type1-Type9

11.14 Phone settings >> MCAST

This feature allows user to make some kind of broadcast call to people who are in multicast group. User can configure a multicast DSS Key on the phone, which allows user to send a Real Time Transport Protocol (RTP) stream to the pre-configured multicast address without involving SIP signaling. You can also configure the phone to receive an RTP stream from pre-configured multicast listening address without involving SIP signaling. You can specify up to 10 multicast listening addresses.

Picture 41 - MCAST

Table 19 - Multicast parameters

Parameters	Description
Normal Call Priority	Define the priority of the active call, 1 is the highest priority, 10 is the lowest.
Enable Page Priority	The voice call in progress shall take precedence over all incoming paging

	calls.
Name	Listened multicast server name
Host: port	Listened multicast server's multicast IP address and port.

11.15 Phone settings >> Action

Action URL

Note! Action urls are used for IPPBX systems to submit phone events. Please refer to Fanvil Action URL for details.

<http://www.fanvil.com/Uploads/Temp/download/20180920/5ba3641fe81a5.pdf>

11.16 Phone settings >> Time/Date

The user can configure the time Settings of the phone on this page.

Table 20 - Time&Date settings

Parameters	Description
Network Time Server Settings	
Time Synchronized via SNTP	Enable time-sync through SNTP protocol
Time Synchronized via DHCP	Enable time-sync through DHCP protocol
Primary Time Server	Set primary time server address
Secondary Time Server	Set secondary time server address, when primary server is not reachable, the device will try to connect to secondary time server to get time synchronization.
Time Zone	Select the time zone
Resync Period	Time of re-synchronization with time server
12-Hour Clock	Set the time display in 12-hour mode
Date Format	Select the time/date display format
Daylight Saving Time Settings	
Local	Choose your local, phone will set daylight saving time automatically based on the local
DST Set Type	Choose DST Set Type, if Manual, you need to set the start time and end time.
Fixed Type	Daylight saving time rules are based on specific dates or relative rule dates for conversion. Display in read-only mode in automatic mode.
Offset	The offset minutes when DST started

Month Start	The DST start month
Week Start	The DST start week
Weekday Start	The DST start weekday
Hour Start	The DST start hour
Minute Start	The DST start minute
Month End	The DST end month
Week End	The DST end week
Weekday End	The DST end weekday
Hour End	The DST end hour
Minute End	The DST end minute
Manual Time Settings	You can set your time manually

11.17 Phone Settings >> Time Plan

Details refer to **Fanvil Time Plan**

Time Plan:

Type:

Timed reboot

Repetition period:

No repetition

☐ 1
☐ 2
☐ 3
☐ 4
☐ 5
☐ 6
☐ 7
☐ 8
☐ 9
☐ 10

Monthly:

Effective time:

0 : 0 - 0 : 0

Add

Time Plan List

☐ Index	Type	Number	Line	Repetition period	Effective time
Delete					

11.18 Phone settings >> Tone

This page allows users to configure a phone prompt.

You can either select the country area or customize the area. If the area is selected, it will bring out the following information directly. If you choose to customize the area, you can modify the button tone, call back tone and other information.

Tone Settings

Select Your Tone:	United States	?
Dial Tone:	350+440/0	?
Ring Back Tone:	440+480/2000,0/4000	?
Busy Tone:	480+620/500,0/500	?
Congestion Tone:		?
Call waiting Tone:	440/300,0/10000,440/300,0/10000,0/0	?
Holding Tone:		?
Error Tone:		?
Stutter Tone:		?
Information Tone:		?
Dial Recall Tone:	350+440/100,0/100,350+440/100,0/100,350+440/100,0/100,350+440/0	?
Message Tone:		?
Howler Tone:		?
Number Unobtainable Tone:	400/500,0/6000	?
Warning Tone:	1400/500,0/0	?
Record Tone:	440/500,0/5000	?
Auto Answer Tone:		?

Apply


Picture 42 - Tone settings on the web

11.19 Phone settings >> Advanced

User can configure the advanced configuration settings in this page.

- Screen Configuration.
 - Set the brightness level in use from 1 to 16,
 - Set the brightness level in the energy-saving mode from 0 to 16
 - Set the backlight time to 30 seconds by default. You can turn it off or select 15 seconds /30 seconds /45 seconds /60 seconds /90 seconds /120 seconds
 - The screen saver can be turned
 - Timeout to Screensaver

Web interface: enter [phone setting] >> [advanced], edit screen parameters, and click submit to save.



Screen Configuration

Backlight Active Level: (1~16)

Backlight Inactive Level: (0~16)

Backlight Time: (0~54000)second(s)

Screensaver: ▼

Timeout to Screensaver: (0~120)second(s)

Picture 43 - Page screen Settings

- UI 显示
 - 空闲时间字体
 - 默认标题字体
 - Softkey 字体
 - 滚动条
 - 警告主题
 - 通知主题
 - 通话字体
 - Hotel profile Font
 - Standby custom Font

- 欢迎词

The greeting message will display on the top left corner of the LCD when the device is idle, which is limited to 16 characters. The default chars are 'VOIP PHONE'.

- 酒店概况
- 自定义显示

11.20 Phonebook >> Advanced

Users can export the local phone book in XML, CSV, and VCF format and save it on the local computer.

Users can also import contacts into the phone book in XML, CSV, and VCF formats.

Attention! If the user imports the same phone book repeatedly, the same contact will be ignored. If the name is the same but the number is different, the contact is created again.

Users can delete groups or add new groups on this page. Deleting a contact group does not delete contacts in that group.

11.21 Call Log

The user can browse the complete call record in this page. The call record can be sorted by time. Call number, contact name or line, and the call record can be screened by call record type (incoming call, outgoing call, missed call, forward call).

11.22 Function Key >> Softkey

The User Settings mode and display style, display page.

Table 21 - Softkey configuration

Parameter	Description
Softkey Mode	
Softkey mode	Disabled and More, Default is Disabled
Softkey Style	
Softkey display style	Softkey Exit on Left or Right
Screen	
Call Dialer	2aB/Delete/Exit/Call Back/Dial/MWI/Dialed/Pause/Next line/Prev line/Audio/Video/DSS Key
Desktop	Prev Account/Next Account/Call Back/Call Forward/DND/MWI/Reboot/Redial/Status/Network/DSS Key
Divert Dialed	Send/2aB/Delete/Exit/Forward/Clear/DSS Key
Ending	Redial/End/Release/DSS Key
Predictive Dialer	Dial/2aB/Delete/Exit/Call Back/Pickup/MWI/Release/Pause/Dialed/Video/Audio/Next line/Prev line/DSS Key
Ringing	Next call/Prev call/Answer/Forward/Reject/Mute/Release/Video/Audio/DSS key
Talking	Hold/Transfer/End/Mute/Release/New Call/Listen/Next call/Prev call/Private/Headset/Video/Audio/DSS Key
Transfer Alerting	End/Transfer/Release/DSS Key
Transfer Dialer	Delete/Exit/2aB/Dial/Transfer/Clear/Missed/Pause/Video/Audio/DSS Key
Trying	End/Release/DSS Key
Waiting	Next call/Prev call/ Release /Answer/Transfer/Forward/Hold/End/Mute/New call/Reject/Prev call/Listen/Video/Audio/DSS Key

You can customize the configuration, Softkey functions and Settings on the web page.

Table 22 - Side Key configuration

Parameters	Description
Memory Key	Presence: the Presence is able to view whether the user is online. Note: You cannot subscribe the same number for BLF and Presence at the same time Speed Dial: You can call the number directly which you set. This feature is convenient for you to dial the number which you frequently dialed. Intercom: This feature allows the operator or the secretary to connect the phone quickly; it is widely used in office environments.
Line	It can be configured as a Line Key. User is able to make a call by pressing Line Key.
Key Event	User can select a key event as a shortcut to trigger. For example: Redial / END / Hold / etc.
DTMF	It allows user to dial or edit dial number easily.
URL	Open the specific URL directly.
Multicast	Configure the multicast address and audio codec. User presses the key to initiate the multicast.
XML browser	Users can set the DSS Key for specific URL download and other operations.

11.23 Security >> Web Filter

The user can set up a configuration management phone that allows only machines with a certain network segment IP access.

Web Filter Table ?

Start IP Address	End IP Address	Option
------------------	----------------	--------

Web Filter Table Settings

Start IP Address ?
End IP Address ?

Web Filter Setting ?

Enable Web Filter ☐

Picture 44 - Web Filter settings



Web Filter Table ?

Start IP Address	End IP Address	Option
172.12.5.50	172.16.5.53	Modify Delete

Picture 45 - Web Filter Table

Adding and removing IP segments are accessible. Configure the starting IP address within the start IP, end the IP address within the end IP, and click **[Add]** to submit to take effect. A large network segment can be set, or it can be divided into several network segments to add. If the user wants to delete, select the initial IP of the network segment to be deleted from the drop-down menu, and then click **[Delete]** to take effect.


Enable web page filtering: configure enable/disable web page access filtering; Click the "apply" button to take effect.

Note: if the device you are accessing is in the same network segment as the phone, please do not configure the filter segment of the web page to be outside your own network segment, otherwise you will not be able to log in the web page.

11.24 Security >> Trust Certificates

Set whether to open license certificate and general name validation, select certificate module.

You can upload and delete uploaded certificates.



Permission Certificate

Permission Certificate: ?

Common Name Validation: ?

Certificate mode: ?

Import Certificates ?

Load Server File:

Certificates List ?

Index	File Name	Issued To	Issued By	Expiration	File Size
					Delete

Picture 46 - Certificate of settings

11.25 Security >> Device Certificates

Select the device certificate as the default and custom certificate.

You can upload and delete uploaded certificates.

The screenshot shows the 'Device Certificates' section of a web interface. It includes a dropdown menu for 'Device Certificates' with options 'Default Certificates' and 'Custom Certificates'. Below this is the 'Import Certificates' section with a 'Load Server File' input field and 'Select' and 'Upload' buttons. At the bottom is the 'Certification File' table with columns: File Name, Issued To, Issued By, Expiration, File Size, and a 'Delete' button.

Picture 47 - Device certificate setting

11.26 Security >> Firewall

The screenshot shows the 'Firewall Settings' section. It starts with 'Firewall Type' and checkboxes for 'Enable Input Rules' and 'Enable Output Rules', followed by an 'Apply' button. Below are two empty tables for 'Firewall Input Rule Table' and 'Firewall Output Rule Table', both with columns: Index, Deny/Permit, Protocol, Src Address, Src Mask, Src Port Range, Dst Address, Dst Mask, and Dst Port Range. The 'Firewall Settings' section contains fields for 'Input/Output' (set to Input), 'Src Address', 'Dst Address', 'Deny/Permit' (set to Deny), 'Src Mask', 'Dst Mask', 'Protocol' (set to UDP), 'Src Port Range', and 'Dst Port Range'. An 'Add' button is next to the 'Dst Mask' field. At the bottom is the 'Rule Delete Option' section with 'Input/Output' (set to Input), 'Index To Be Deleted' input field, and a 'Delete' button.

Picture 48 - Network firewall Settings

The user can set whether to enable the input through this page, output firewall and set the firewall input and output rules. Using these Settings can prevent some malicious network access, or restrict internal users access to some resources of the external network, which can improve security.

Firewall rule set is a simple firewall module. This feature supports two types of rules: input rules and output


rules. Each rule is assigned an ordinal number, allowing up to 10 for each rule.

Considering the complexity of firewall Settings, the following is an example to illustrate:

Table 23 - Network Firewall

Parameter	Description
Enable Input Rules	Indicates that the input rule application is enabled.
Enable Output Rules	Indicates that the output rule application is enabled.
Input/Output	To select whether the currently added rule is an input or output rule.
Deny/Permit	To select whether the current rule configuration is disabled or allowed;
Protocol	There are four types of filtering protocols: TCP UDP ICMP IP.
Src Port Range	Filter port range
Src Address	Source address can be host address, network address, or all addresses 0.0.0.0; It can also be a network address similar to *.*.*.0, such as: 192.168.1.0.
Dst Address	The destination address can be either the specific IP address or the full address 0.0.0.0; It can also be a network address similar to *.*.*.0, such as: 192.168.1.0.
Src Mask	Is the source address mask. When configured as 255.255.255.255, it means that the host is specific. When set as 255.255.255.0, it means that a network segment is filtered.
Dst Mask	Is the destination address mask. When configured as 255.255.255.255, it means the specific host. When set as 255.255.255.0, it means that a network segment is filtered.

After setting, click **[Add]** and a new item will be added in the firewall input rule, as shown in the figure below:




Index	Deny/Permit	Protocol	Src Address	Src Mask	Src Port Range	Dst Address	Dst Mask	Dst Port Range
1	deny	udp	192.168.1.0	192.168.1.154	0-9	255.255.255.0	255.255.255.0	0-9

Picture 49 - Firewall Input rule table

Then select and click the button **[Apply]**.

In this way, when the device is running: ping 192.168.1.118, the packet cannot be sent to 192.168.1.118 because the output rule is forbidden. However, the other IP of the ping 192.168.1.0 network segment can still receive the response packet from the destination host normally.



Rule Delete Option

Input/Output:

Index To Be Deleted:

Picture 50 - Delete firewall rules

Select the list you want to delete and click **[Delete]** to delete the selected list.

11.27 Device Log >> Device Log

You can grab the device log, and when you encounter an abnormal problem, you can send the log to the technician to locate the problem. See [13.6 Get log information](#).

12 Trouble Shooting

When the phone is not in normal use, the user can try the following methods to restore normal operation of the phone or collect relevant information and send a problem report to Fanvil technical support mailbox.

12.1 Get Device System Information

Users can get information by pressing the **[Network] >> [Phone]** option in the phone. The following information will be provided:

The network information

Equipment information (model, software and hardware version), etc.

12.2 Reboot Device

Users can use the webpage **[system] >> [Reboot System]** and press **[ok]**, or simply remove the power supply and restore it again.


12.3 Reset Device to Factory Default

Resetting Device to Factory Default will erase all the user's configuration, database and profiles on the device and restore the device back to the state as factory default.

User restore factory reset press **[system] >> [Configuration] >> [Reset Phone]** and press **[reset]**. The phone will revert to the factory default state.

12.4 H5W Screenshot

If there is a problem with the phone, the screenshot can help the technician locate the function and identify the problem. In order to obtain screen shots, log in the phone webpage **[System] >> [Tools]**, and you can capture the pictures of the screen (you can capture them in the interface with problems).



Picture 51 - Screenshot

12.5 Network Packets Capture

Sometimes it is helpful to dump the network packets of the device for issue identification. To get the packets dump of the device, user needs to log in the device web portal, open page **[System] >> [Tools]** and click **[Start]** in “Network Packets Capture” section. A pop-up message will be prompt to ask user to save the capture file. User then should perform the relevant operations such as activating/deactivating line or making phone calls and click **[Stop]** button in the web page when operation finished. The network packets of the device during the period have been dumped to the saved file.



Picture 52 - Web capture

User may examine the packets with a packet analyzer or send it to Fanvil support mailbox.

12.6 Get Log Information

Log information is helpful when encountering an exception problem. In order to get the log information of the phone, the user can log in the phone web page, open the page **[Device log]**, click the **[Start]** button, follow the steps of the problem until the problem appears, and then click the **[End]** button, **[Save]** to local analysis or send the log to the technician to locate the problem.

12.7 Common Trouble Cases

Table 24 - Trouble Cases

Trouble Case	Solution
Device could not boot up	1. The device is powered by external power supply via power adapter or PoE switch. Please use standard power adapter provided by manufacturer or PoE switch met with the specification requirements and check if device is well connected to power source. 2. If you saw "POST MODE" on the device screen, the device system image has been damaged. Please contact location technical support to help you restore the phone system.
Device could not register to a service provider	1. Please check if device is well connected to the network. The network Ethernet cable should be connected to the  [Network] port NOT the  [PC] port. If the cable is not well connected to the network icon  [WAN disconnected] will be flashing in the middle of the screen. 2. Please check if the device has an IP address. Check the system information, if the IP displays "Negotiating...", the device does not have an IP address. Please check if the network configurations is correct. 3. If network connection is fine, please check again your line configurations. If all configurations are correct, please kindly contact your service provider to get support, or follow the instructions in "13.5 Network Packet Capture" to get the network packet capture of registration process and send it to manufacturer support to analyze the issue.
No Audio or Poor Audio in Handset	1. Please check if Handset is connected to the correct 2. The network bandwidth and delay may be not suitable for audio call at the moment.
Audio is chopping at far-end in Hands-free speaker mode	This is usually due to loud volume feedback from speaker to microphone. Please lower down the speaker volume a little bit, the chopping will be gone.

