

Wind Sensor - Standard



Specification	Order No.	Packing unit	PS	EAN
	0913 00	1	06	4010337913009

Features

Wind transmitter (cup anemometer/anemometer)

- The wind sensor enables raising of the blinds depending on the strength of the wind, for example. In this way, sensitive blind slats can be protected from increasing wind.
- The wind transmitter is used to convert the wind speed into electrical signals.
- It is mounted on the roof or on the side of the building and connected to the evaluation unit.

Evaluation unit

- Test mode with test LED.
- Distributor terminals for connecting a heated wind signaller.

Technical data

Wind transmitter

- | | |
|---|--|
| - Material of the transmitter and cup anemometer: | Plastic (ABS), black |
| - Ambient temperature: | -25 °C to +60 °C |
| - Connection cable: | LIYY 2 x 0.14 mm², length 3 m (can be extended to max. 50 m) |

Evaluation unit

- | | |
|-----------------------|--|
| - Wind warning range: | 3.3 to 24.5 m/s, can be set to one of 8 levels |
| - Switching contact: | Relay with zero-voltage NO contact |
| - Load capacity: | max. 2 A |
| - Operating voltage: | AC 230 V |

Scope of supply

- Mounting bracket included in the scope of supply.

Dimensions in mm

Cup diameter of the wind transmitter: Ø 134 H 160
