



USB-C 3.2 Gen2 10Gbps NVMe / SATA M.2 SSD RGB enclosure

MS13




Installation Guide / Installationsanleitung / Guide d'installation
Guía de instalación / Guida all'installazione / Руководство по установке
インストールガイド / 설치 가이드 / คู่มือการติดตั้ง / 安裝說明 / 安装说明

Warranty terms & conditions / Garantiebedingungen
Términos y condiciones de la garantía / Termes et conditions de la garantie /
Termini e Condizioni della garanzia / Условия гарантии / 保証条件 / 보증 조건
ข้อกำหนดและเงื่อนไขการรับประกัน / 有限責任保固說明 / 有限責任保固说明

Preparation

1



ENGLISH

Unfasten the screws and take out the PCB

DEUTSCH

Schrauben lösen und Leiterplatte herausnehmen

FRANÇAIS

Dévissez les vis et retirez le circuit imprimé

ESPAÑOL

Afloje los tornillos y saque el PCB

ITALIANO

Svitare le viti ed estrarre la PCB

ไทย

คลายสกรู และถอด PCB ออก

РУССКИЙ

Открутите винты и выньте плату

繁體中文

鬆開螺絲，取出PCB

簡體中文

松开螺丝，取出PCB

日本語


ネジを外してPCBを取り外します

한국어

나사를 풀러, PCB를 꺼냅니다

Preparation

2



ENGLISH

Install M.2 SSD

РУССКИЙ

Установите M.2 SSD

DEUTSCH

M.2-SSD installieren

繁體中文

安裝M.2 SSD

FRANÇAIS

Installez le SSD M.2

簡體中文

安装 M.2 SSD

ESPAÑOL

Instale el SSD M.2

日本語

M.2 SSDをインストールします

ITALIANO

Installare l'SSD M.2

한국어


M.2 SSD를 장착합니다

ไทย

ติดตั้ง M.2 SSD

Preparation

3



ENGLISH

Attach the thermal pads and remove the film

РУССКИЙ

Установите термопрокладки и снимите плёнку

DEUTSCH

Wärmefallen anbringen und Folie entfernen

繁體中文

貼上導熱貼片並移除膠膜

FRANÇAIS

Fixez les coussinets thermiques et retirez le film

簡體中文

貼上導熱貼片并移除膠膜

ESPAÑOL

Fije las almohadillas térmicas y quite la película protectora

日本語

サーマルパッドのフィルムをはがして貼付します

ITALIANO

Fissare i pad termici e rimuovere la pellicola

한국어


써멀 패드를 붙이고, 필름을 제거합니다

ไทย

ติดแผ่นระบายความร้อน และลอกฟิล์มออก

Preparation

4



ENGLISH

Align the aluminum plate with the mounting holes, then lightly press to ensure a tight fit

DEUTSCH

Aluminiumplatte an den Montageöffnungen ausrichten, dann zur Gewährleistung einer festen Passung leichten Druck ausüben

FRANÇAIS

Alignez la plaque d'aluminium avec les trous de montage, puis appuyez légèrement pour assurer un bon ajustement

ESPAÑOL

Alinee la placa de aluminio con los agujeros de montaje, luego presione ligeramente para asegurar un buen encaje

ITALIANO

Allineare la piastra di alluminio con i fori di montaggio, quindi premere leggermente per garantire una perfetta aderenza

ไทย

จัดแผ่นอลูมิเนียมให้ตรงกับรูยึด จากนั้นกดเบาๆ เพื่อให้แน่ใจว่าเข้าที่แน่น

РУССКИЙ

Совместите алюминиевую пластину с монтажными отверстиями, затем слегка нажмите, чтобы обеспечить плотную посадку

繁體中文

對齊螺絲位置後貼上鋁片，並輕壓確保密合

簡体中文

对齐螺丝位置后贴上铝片，并轻压确保密合

日本語


アルミニウム板を取り付け孔に合わせ、軽く押してフィットさせます

한국어

장착 홀에 알루미늄 플레이트를 맞춘 후, 가볍게 눌러 단단히 고정되었는지 확인합니다

Preparation

5



ENGLISH

Place the assembled PCB into the aluminum alloy case and fasten with screws

DEUTSCH

Montierte Leiterplatte im Gehäuse aus Aluminiumlegierung platzieren und mit Schrauben befestigen

FRANÇAIS

Placez le circuit imprimé assemblé dans le boîtier en alliage d'aluminium et fixez-le avec des vis

ESPAÑOL

Coloque el PCB ensamblado en la carcasa de aluminio y fije con tornillos

ITALIANO

Posizionare la PCB assemblata nel case in lega di alluminio e fissarla con le viti.

ไทย

ใส่ PCB ที่ประกอบแล้วลงในเคสอลูมิเนียมอัลลอย แล้วขันสกรูให้แน่น

РУССКИЙ

Поместите собранную плату в корпус из алюминиевого сплава и закрепите винтами

繁體中文

將組裝完成的PCB裝入鋁殼中並鎖上螺絲

簡體中文

将组装完成的PCB装入铝壳中并锁上螺丝

日本語

組まれたPCBをアルミニウム合金ケースに収めて、ネジで固定します

한국어

조립이 완료된 PCB를 알루미늄 합금 케이스에 넣고, 나사로 조입니다

Warranty terms & conditions

Warranty Information

This product has a limited 1 year warranty in North America and Australia.
For information on warranty periods in other regions, please contact your reseller or SilverStone authorized distributor.

本产品自购买之日起，于中国地区（不包含澳门，香港特别行政区）享有一年有限责任保固（部分产品为二年，三年或五年）。
详细保固年限请参照官方网站 <https://silverstonetek.com.cn/> 公布之产品型号为依据。

Warranty terms & conditions

- Product component defects or damages resulted from defective production is covered under warranty.
Defects or damages with the following conditions will be fixed or replaced under SilverStone Technology's jurisdiction.
 - Usage in accordance with instructions provided in this manual, with no misuse, overuse, or other inappropriate actions.
 - Damage not caused by natural disaster (thunder, fire, earthquake, flood, salt, wind, insect, animals, etc...)
 - Product is not disassembled, modified, or fixed. Components not disassembled or replaced.
 - Warranty mark/stickers are not removed or broken.Loss or damages resulted from conditions other than ones listed above are not covered under warranty.
- Under warranty, SilverStone Technology's maximum liability is limited to the current market value for the product (depreciated value, excluding shipping, handling, and other fees). SilverStone Technology is not responsible for other damages or loss associated with the use of product.
- Under warranty, SilverStone Technology is obligated to repair or replace its defective products. Under no circumstances will SilverStone Technology be liable for damages in connection with the sale, purchase, or use including but not limited to loss of data, loss of business, loss of profits, loss of use of the product or incidental or consequential damage whether or not foreseeable and whether or not based on breach of warranty, contract or negligence, even if SilverStone Technology has been advised of the possibility of such damages.
- Warranty covers only the original purchaser through authorized SilverStone distributors and resellers and is not transferable to a second hand purchaser.
- You must provide sales receipt or invoice with clear indication of purchase date to determine warranty eligibility.
- If a problem develops during the warranty period, please contact your retailer/reseller/SilverStone authorized distributors or SilverStone <http://www.silverstonetek.com>.
Please note that: (i) You must provide proof of original purchase of the product by a dated itemized receipt; (ii) You shall bear the cost of shipping (or otherwise transporting) the product to SilverStone authorized distributors. SilverStone authorized distributors will bear the cost of shipping (or otherwise transporting) the product back to you after completing the warranty service; (iii) Before you send the product, you must be issued a Return Merchandise Authorization ("RMA") number from SilverStone. Updated warranty information will be posted on SilverStone's official website.
Please visit <http://www.silverstonetek.com> for the latest updates.

Additional info & contacts

For North America (usasupport@silverstonetek.com)
SilverStone Technology in North America may repair or replace defective product with refurbished product that is not new but has been functionally tested. Replacement product will be warranted for remainder of the warranty period or thirty days, whichever is longer. All products should be sent back to the place of purchase if it is within 30 days of purchase, after 30 days, customers need to initiate RMA procedure with SilverStone Technology in USA by first downloading the "USA RMA form for end-users" form from the below link and follow its instructions.
<http://silverstonetek.com/contactus.php>

For Australia only (support@silverstonetek.com)
Our goods come with guarantees that cannot be excluded under the Australian Consumer Law.
You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage.
You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.
Please refer to above "Warranty terms & conditions" for further warranty details.

SilverStone Technology Co., Ltd. 12F No. 168 Jiankang Rd., Zhonghe Dist., New Taipei City 235 Taiwan R.O.C. + 886-2-8228-1238
(standard international call charges apply)

For Europe (support.eu@silverstonetek.de)
For China (support@silverstonetek.com.cn)
For all other regions (support@silverstonetek.com)

有毒有害物质/元素及其化学含量表

部件名称 (周边产品)	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
机壳(金属)	○	○	○	○	○	○
电子卡	○	○	○	○	○	○
螺丝	○	○	○	○	○	○
包材	○	○	○	○	○	○
导热贴	○	○	○	○	○	○

辅助材:是指使用在产品上的涂料, 润滑脂、焊接材料、接着剂等, 以及与产品包装, 作为施工材料使用的粘接胶带、密封材料、接着剂等

本表格依据 SJ/T 11364 的规定编制。

○ : 表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。

— : 表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 规定的限量要求。且该限用物质为排除项目

产品合格证

检验员: 检01

生产日期: 见产品条码