thermaltake

SWAFAN EX RGB
PC Cooling Fan

Scan Here
Installation Guide

Parts List



Ⓐ x 3	Ⓑ x 3	Ⓒ x 1	Ⓓ x 1	Ⓔ x 1	Ⓕ x 1	Ⓖ x 1	Ⓗ x 3	Ⓘ x 12	Ⓙ x 12	Ⓚ x 1
Fan & Standard Fan Blade	Reverse Fan Blade	Controller	Lubricant	Controller Cable	Bridge Cable	Power Cable	Signal Cable	Short Screw	Long Screw	Velcro

Installation Guide

1 Choose your fan blade type

Standard Fan Blade (Pre installed on the fan Ⓐ)

Airflow Direction:
Air Exhaust



Reverse Fan Blade

Airflow Direction:
Air Intake



2 Replace fan blades



3



4



5



Install the fans properly onto the radiator.

Oil Setup Guide



After replacing the fan blades several times,
readd the oil into the bearing (about 0.1ml)

Controller Installation Guide

1



Connect the fans to the controller.

2



Set the DIP switch on the back side of the controller to assign the number of the controller

NO.1
ON
1 2 3 4

NO.2
ON
1 2 3 4

NO.3
ON
1 2 3 4

NO.4
ON
1 2 3 4

NO.5
ON
1 2 3 4

NO.6
ON
1 2 3 4

NO.7
ON
1 2 3 4

NO.8
ON
1 2 3 4

NO.9
ON
1 2 3 4

NO.10
ON
1 2 3 4

NO.11
ON
1 2 3 4

NO.12
ON
1 2 3 4

NO.13
ON
1 2 3 4

NO.14
ON
1 2 3 4

NO.15
ON
1 2 3 4

NO.16
ON
1 2 3 4

3



Connect the controller cable onto the motherboard (USB 2.0 9 pin) and controller.

4



Connect the power cable to the 4pin Molex connecter and controller.

5



If you want to connect two or more controllers, you can sync the controllers with the bridge connector.

RoHS COMPLIANT UKCA CE

© 2022 Thermaltake Technology Co., Ltd. All Rights Reserved.
www.thermaltake.com

thermaltake