





VESA ADAPTER KIT

Assembly & Installation






Dimension




Identify your TV's VESA hole pattern



Assembly for various VESA patterns


Width< 400mm (15.8")



W × H



200mm × 100mm (7.87" × 3.9")
 200mm × 200mm (7.87" × 7.87")
 300mm × 200mm (11.8" × 7.87")
 300mm × 300mm (11.8" × 11.8")

Width > 400mm (15.8")




W × H


600mm × 200mm (23.6" × 7.87")
 600mm × 300mm (23.6" × 11.8")
 600mm × 400mm (23.6" × 15.8")



1





2





i Assemble VESA adapter plates based on the width of your VESA pattern.

3




Use measuring tape to measure the height of your VESA pattern.

4




5






Use the TV mounting hardware included with Heckler AV cart.

6



Use the TV mounting hardware included with Heckler AV cart.





Shelf installation hardware included with Heckler AV Cart and Heckler Multi Shelf.

