

SUMMIT 20000

Low Temperature Resistant
Carbon Fiber Power Bank

- Ultra Compact and Lightweight
- Fast Charging Capability
- Low Temperature Heating Mode



IMPORTANT NOTICE CONCERNING WARRANTY SERVICE

Thank you for purchasing! Before using this product, please find your verification code on the package box, and go to <http://charger.nitecore.com/validation> (or scan the QR code beside the verification code to visit on your mobile phone). Type in your verification code and personal information as required, and submit the page. After verification, NITECORE will send you a warranty service email for a free warranty extension of 6 months. This email and your registration email address are essential to your possible warranty application.

SYSMAX Innovations Co., Ltd.

Our authorized dealers and distributors are responsible for warranty service. Should any problem covered under warranty occurs, customers can contact their dealers or distributors in regards to their warranty claims, as long as the product was purchased from an authorized dealer or distributor. NITECORE's Warranty is provided only for products purchased from an authorized source. This applies to all NITECORE products. Any DOA / defective product can be exchanged for a replacement through a local distributor/dealer within the first 15 days of purchase. After 15 days, all defective / malfunctioning NITECORE® products can be repaired free of charge for a period of 12 months (1 year) from the date of purchase. Beyond 12 months (1 year), a limited warranty applies, covering the cost of labor and maintenance, but not the cost of accessories or replacement parts. For an optional free warranty extension of 6 months, please refer to the "IMPORTANT WARRANTY NOTICE" section on top to validate your product. The warranty is nullified if the product(s) is/are:

1. broken down, reconstructed and/or modified by unauthorized parties
 2. damaged from wrong operations
- For the latest information on NITECORE® products and services, please contact a local NITECORE® distributor or send an email to service@nitecore.com.

※ All images, text and statements specified herein this user manual are for reference purpose only. Should any discrepancy occur between this manual and information specified on www.nitecore.com, information on our official website shall prevail. SYSMAX Innovations Co., Ltd. reserves the rights to interpret and amend the content of this document at any time without prior notice.

TEL: +86-20-83862000
FAX: +86-20-83882723
E-mail: info@nitecore.com
Web: www.nitecore.com
Address: Unit 6355, 5/F,
No. 1021 Gaopu Road,
Tianhe District, Guangzhou,
510653, Guangdong, China

Please find us on facebook : [nitecorecharger](https://www.facebook.com/nitecorecharger)
Thanks for purchasing NITECORE!


SUMMIT160320K23

Technical Data

Cell:	Li-ion
Capacity:	20,000mAh 3.85V (77Wh)
Rated Energy:	13,500mAh 5V (TYP 2A)
Input:	USB-C: 5V~2.4A / 9V~2A
Output:	USB-C: 5V~3A / 9V~2.22A / 12V~1.68A
	USB-A: 5V~3A / 9V~2A / 12V~1.5A
Dual Ports:	5V~3A (MAX)
IP Rating:	IPX5
Dimensions:	124mm x 60mm x 21.8mm (4.88" x 2.36" x 0.86")
Weight:	303g±5g (10.69 oz±0.1 oz) (Accessories Not Included)
Accessories:	USB-C to USB-C Charging Cable, Insulation Carrying Bag

Note: It is recommended to use the product with the Insulation Carrying Bag in low temperature environment (below 0°C / 32°F).

Operating Instructions



（日本語）

使用方法

モードボタンを短く押すと電池残量が表示されます。
モードボタンをダブルクリックするとオフになります。

インジケーター

SUMMIT 2000 は 2 種類のインジケーターを搭載しています。4つの青色パワーインジケーターは、充電状況や電池残量を表示し、モードインジケーターは、低電流モードでは白色、低温加熱モードでは赤色に点灯します。

電池残量の確認

モードボタンを短く押すと、青色インジケーターが点灯して電池残量を表示します。
ノート：The SUMMIT 20000 はしばらく操作をせず低温加熱モードも動いていない場合、自動的に休止モードとなります。

充電方法

充電中はパワーインジケーターが点滅して充電レベルをお知らせします。充電が完了すると 4 つ全てのパワーインジケーターが点灯状態となります。

外部デバイスの充電

充電中はパワーインジケーターが点灯して電池残量を表示します。

低電流モード：

このモードは、ワイヤレスイヤホンやウェアラブル端末などの低電流での充電が必要なデバイス用です。モードボタンを長押しするとモードインジケーターが白色で点灯し、低電流モードになります。モードボタンをもう一度長押しするとモードインジケーターが消灯し、低電流モードが終了します。(低電流モードは自動的にオフにならないため、低電流充電での充電が終わったら、低電流モードを手動で解除してください)

低温加熱モード：

オン：

- SUMMIT 20000 の温度が 0℃以下だった場合、モードボタンを短く押すと低温加熱モードになります。加熱しているときモードインジケーターは赤色で点灯します。
- SUMMIT 20000 の温度が 0℃以下で、インポートまたはアウトプットで使用している場合、自動的に低温加熱モードになります。

ノート：

- 使用環境温度が-10℃以上だった場合、SUMMIT 20000 はそのまま使用することができません。
- 使用環境温度が-10℃以下だった場合、使い始める前に 5-10 分加熱する必要があります。

オフ：低温加熱モードがオンの時、モードボタンをダブルクリックすると低温加熱モードから抜けて、休止モードになります。(低温加熱モードは自動的にオフにならないため、低温加熱モードが必要なくなったら、手動で解除してください)

注意事項

- 使用される前に本マニュアルをよく確認いただき、本マニュアルに記載されている規格に対応した外部デバイスにのみご使用ください。
- 長期使用しない時は 3 ヶ